



Installation Instructions *Rev.02*

LOAD LEVELING KIT **88-22230 FORD F-250 (2023+)** **(WITHOUT OVERLOAD SPRINGS)**

READ INSTRUCTIONS THOROUGHLY
AND COMPLETELY BEFORE INSTALLATION.

INSTALLATION BY A CERTIFIED
PROFESSIONAL MECHANIC IS HIGHLY RECOMMENDED.

LOGIQ™ IS NOT RESPONSIBLE FOR ANY DAMAGE
OR FAILURE RESULTING FROM IMPROPER INSTALLATION.

WARRANTY

LOGIQ™ provides a limited lifetime warranty to the original purchaser of products, that the product be free from defects in workmanship and materials when used on cars and trucks as specified by LOGIQ™ and under normal operating conditions. This warranty is subject to the requirements and exclusions set forth in the full Limited Warranty and Return Policy that is available at logiqair.com/warranty. Air compressors are a wearing component and are covered by a 2-year warranty from the date of purchase. The warranty does not provide coverage for abuse, operation in a manner not consistent with the product's design, or damage resulting from exposure to the elements.



WARNING & DISCLAIMERS

By installing this product you acknowledge that the suspension of this vehicle has been modified. As a result, this vehicle may handle differently than that of factory-equipped vehicles. As with any vehicle, extreme care must be used to prevent loss of control or roll-over during sharp turns or abrupt maneuvers. Always wear seat belts, and drive safely, recognizing that reduced speeds and specialized driving techniques may be required. Failure to drive this vehicle safely may result in serious injury or death. Do not drive this vehicle unless you are familiar with its unique handling characteristics and are confident of your ability to maintain control under all driving conditions. Some modifications (and combinations of modifications) are not recommended and may not be permitted in your state. Consult your owner's manual, the instructions accompanying this product, and state laws before undertaking these modifications. You are responsible for the legality and safety of the vehicle you modify using these components.



Installation Instructions
LOAD LEVELING KIT
88-22230 FORD F-250 (2023+)
(WITHOUT OVERLOAD SPRINGS)

TOOLS REQUIRED
SAFETY GLASSES
9/16" DEEP SOCKET
15/16" SOCKET
8MM SOCKET
11MM WRENCH
15MM DEEP SOCKET
17MM SOCKET
1/2" DRIVE EXTENSION
12MM WRENCH (X2)
JACK & JACK STANDS
TORQUE WRENCH
5/16" DRILL BIT & DRILL
AIR LINE CUTTER (RAZOR BLADE)

APPLICATION NOTES
TRUCK COMPATIBILITY
ALL TRUCK VARIATIONS WITHOUT OVERLOAD SPRINGS
5TH WHEEL COMPATIBILITY
OEM 5 TH WHEEL BW GNRK1123

QTY	PARTS INCLUDED
1	DRIVER SIDE AIR SPRING ASSEMBLY
1	PASSENGER SIDE AIR SPRING ASSEMBLY
1	HARDWARE KIT
1	MANUAL INFLATION KIT
HARDWARE KIT CONTENTS	
4	5/8" - 11 X 3.5" HEX HEAD BOLT GRADE 8
4	5/8" - 11 X 4" HEX HEAD BOLT GRADE 8
4	5/8" SPLIT LOCK WASHER
4	5/8" FLAT WASHER
4	AIR SPRING LOWER STRAP
8	3/8" - 16 X 4" CARRIAGE BOLT
8	3/8" - 16 NYLON LOCKING NUT
8	3/8" FLAT WASHER
2	JOUNCE BUMPER SPACER
2	M10 - 16MM HEX BOLT
1	2 ML RED THREADLOCKER PACKET
1	DRIVER SIDE RIDE HEIGHT SENSOR RELOCATION BRACKET
1	PASSENGER SIDE RIDE HEIGHT SENSOR RELOCATION BRACKET
MANUAL INFLATION KIT CONTENTS	
16	8" ZIP TIES
2	INFLATION VALVE TO 1/4" PTC FITTING
1	16' ROLL 1/4" AIR LINE


STEP 1 PREPARE TRUCK

Note original ride height measurement from center of rear fender arch to ground.


Safely lift truck and support with jack stands under axle. Remove the rear wheels.

NOTE: IF YOUR TRUCK IS EQUIPPED WITH REAR HEIGHT SENSORS, REFER TO THE LAST PAGE FOR HEIGHT SENSOR RELOCATION.


STEP 2 INSTALL BUMPSTOP SPACER



Unbolt factory bumpstop using a 15MM socket.



Reinstall factory bumpstop with provided aluminum spacer and M10 bolt.




Repeat for passenger side.

Apply some of the provided thread locker to the bolt before installing.


Torque the M10 bolt to **15 FT. LB.**

Reinstall the factory bumpstop bracket to the frame.

STEP 3 MOUNT AIR SPRING ASSEMBLY (WITHOUT 5TH WHEEL)




Use the supplied 3.5" long Grade 8 5/8" bolts, with split washers and flat washers, to attach the upper air spring bracket to the outside of the frame, through the factory sleeved holes. Snug hardware.




Repeat for passenger side.

STEP 4 MOUNT AIR SPRING ASSEMBLY (WITH 5TH WHEEL)




First remove the 5th wheel frame mounting hardware.



(Driver side)


Use the supplied 4" long Grade 8 5/8" bolts, with split washers and flat washers, to attach the upper air spring bracket to the outside of the hitch, through the factory hitch mounting holes. Snug hardware.



(Passenger side)


Repeat for passenger side.

STEP 5 ATTACH LOWER BRACKET




(Driver side)

Use the supplied 3/8" hardware and leaf spring straps to attach the lower air spring bracket to the leaf spring.



Make sure that the lower bracket is centered over the U-bolt saddle.




(Passenger side)

Repeat for passenger side.


STEP 6 TORQUE HARDWARE

A Torque the 5/8" hardware to **150 FT. LB.**

B Torque the 3/8" hardware to **20 FT. LB.**



(Driver side)



(Passenger side)

STEP 7 AIR LINE ROUTING

When used with an on-board air management system, refer to the on-board air management system installation instructions before routing the air lines.

When not using an on-board air management system, mount inflation valves at desired location using 5/16" drill bit.

Route air line from each inflation valve to each air fitting tee on both of the air spring assemblies. **Avoid hot exhaust and sharp edges. Cut air line square and free from burrs with air line cutter or razor blade!**

STEP 8 FINAL SAFETY CHECKS


Check for leaks at fittings with soapy water.

Check tire clearance to air spring (more than 1")

Verify all fasteners are torqued properly.

Verify at least 10psi in air spring before driving.


HEIGHT SENSOR RELOCATION (IF EQUIPPED)




Remove the height sensor bracket from the leaf pack.

Remove the nut from the height sensor linkage arm ball stud to detach the bracket. Keep the linkage arm nut.

Repeat for passenger side.



When attaching the lower air spring bracket, install the height sensor relocation bracket between the carriage bolts and the lower bracket leg.



Attach the height sensor linkage arm to the relocation bracket using the factory nut.

Torque ball stud nut to **36 IN. LB.**

LOGIQ™ suggests having the height sensors re-calibrated at your local Ford Service Center.



WARNING & DISCLAIMERS CONTINUED

Safety Warnings

MISUSE OF THIS PRODUCT COULD LEAD TO INJURY OR DEATH.

FOR SAFETY AND TO PREVENT POSSIBLE DAMAGE TO THE VEHICLE, DO NOT EXCEED MAXIMUM GROSS VEHICLE WEIGHT RATING (GVWR), MAXIMUM GROSS COMBINED VEHICLE WEIGHT RATING (GCVWR), MAXIMUM GROSS AXLE RATINGS (GAWR), OR MAXIMUM PAYLOAD RATING AS INDICATED BY THE VEHICLE MANUFACTURER.

Suspension systems or components that enhance the on and off-road performance of your vehicle may cause it to handle differently than it did from the factory. Extreme care must be used to prevent loss of control during abrupt maneuvers.

Always operate your vehicle at reduced speeds to ensure your ability to control your vehicle under all driving conditions. Failure to drive safely may result in serious injury or death.

Driver and passengers must **ALWAYS** wear seat belts, avoid quick sharp turns and other sudden maneuvers. LOGIQ™ does not recommend the combined use of suspension lifts, body lifts, or other lifting devices.

You should never operate your vehicle under the influence of alcohol or drugs.

Constant maintenance is required to keep your vehicle safe. Thoroughly inspect your vehicle before and after every off-road use.

It is the responsibility of the retailer and/or the installer to review all state and local laws, with the end user of this product, related to bumper height laws and the lifting of their vehicle before the purchase and installation of any LOGIQ™ products.

Raised vehicles have altered viewing angles than stock vehicles. This can lead to larger or different blind spots than the driver is accustomed. It is the responsibility of the driver to be aware of this and check their surroundings at all times while the vehicle is in motion and immediately prior to operating vehicle. Failure to do so can lead to damages, injury, or death.

Installation Warning

All steps and procedures described in these instructions were performed while the vehicle was properly supported on a two post vehicle lift with safety jacks.

Use caution during all disassembly and assembly steps to ensure suspension components are not over extended causing damage to any vehicle components and parts included in this kit.

Included instructions are guidelines only for recommended procedures and are not meant to be definitive. Installer is responsible to insure a safe and controllable vehicle after performing modifications.

LOGIQ™ recommends the use of an OE Service Manual for model/year of vehicle when disassembly and assembly of factory and related components.

Unless otherwise specified, tighten all bolts and fasteners to standard torque specifications listed within the OE Service Manual.

Suspension components that use rubber or urethane bushings should be tightened with the vehicle at normal ride height. This will prevent premature wear or failure of the bushing and maintain ride comfort.

Larger tire and wheel combinations may increase leverage on suspension, steering, and related components.

Due to payload options and initial ride height variances, the amount of lift/lower is a base figure. Final ride height dimensions may vary in accordance to original vehicle ride height. Always measure the vehicle ride height prior to beginning installation.



WARNING & DISCLAIMERS

SAEJ2492 Warning

By installing this product, you acknowledge that the suspension of this vehicle has been modified. As a result, this vehicle may handle differently than that of factory-equipped vehicles. As with any vehicle, extreme care must be used to prevent loss of control or roll-over during sharp turns or abrupt maneuvers. Always wear seat belts, and drive safely, recognizing that reduced speeds and specialized driving techniques may be required. Failure to drive this vehicle safely may result in serious injury or death. Do not drive this vehicle unless you are familiar with its unique handling characteristics and are confident of your ability to maintain control under all driving conditions. Some modifications (and combinations of modifications) are not recommended and may not be permitted in your state. Consult your owner's manual, the instructions accompanying this product, and state laws before undertaking these modifications. You are responsible for the legality and safety of the vehicle you modify using these components.

Headlamp Warning

A lifted or lowered vehicle may have different headlight aim performance. LOGIQ™ recommends marking and recording the headlight beam position before kit installation and then adjusting, if necessary, the headlamps to the same height settings after kit installation. Set the vehicle on a level surface 10' to 15' from a solid wall or garage door. (This is a general distance with some manufacturers requiring different distances.) Note the top height of the low beam's bright spot, the top of the most intense part of the beam, for driver and passenger side. Height may vary from side to side. Repeat this procedure and adjust after lift kit is installed. Adjust if the aim is off by turning the adjusters gradually (a quarter of a turn) and looking to see where the new alignment falls. It may be easier to block one headlamp while adjusting the other. Consult the owner operation manual for procedures to adjust headlights - many automakers offer headlight aiming specs. Some states have their own specifications when it comes to headlight aim, so it's best to follow those rules when aligning headlights.

FAILURE TO PERFORM THE POST INSPECTION CHECKS MAY RESULT IN VEHICLE COMPONENT DAMAGE AND/OR PERSONAL INJURY OR DEATH TO THE DRIVER AND/OR OTHERS.

Final Checks & Adjustments

Once the vehicle is lowered to the ground, check all parts which have rubber or urethane components to ensure proper torque. Torque lug nuts to the wheel manufacturer specs. Move vehicle backwards and forwards a short distance to allow suspension components to adjust. Turn the front wheels completely left then right and verify adequate tire, wheel, brake line, and ABS wire clearance. Test and inspect steering, brake and suspension components for tightness and proper operation. Inspect brake hoses and ABS lines for adequate slack at full extension, adjust as necessary.

RECHECK ALL HARDWARE FOR PROPER TORQUE VALUES AFTER 500 MILES, AND THEN PERIODICALLY AT EACH SERVICE INTERVAL THEREAFTER.

Vehicle Handling Warning

Increasing the height of your vehicle raises the center of gravity and can affect stability and control. Use caution on turns and when making steering corrections. Vehicles with larger tires and wheels will handle differently than stock vehicles. Take time to familiarize yourself with the handling of your vehicle.

Wheel Alignment/Headlamp Adjustment

It is necessary to have a proper and professional wheel alignment performed by a certified alignment technician. Align the vehicle to factory specifications. It is recommended that your vehicle alignment be checked after any off-road driving.

In addition to your vehicle alignment, for your safety and others, it is necessary to check and adjust your vehicle headlamps for proper aim and alignment. If the vehicle is equipped with active or passive safety/collision monitoring and/or avoidance systems including, but not limited to, camera- or radar-based systems, check and adjust your vehicle's systems for proper aim and function.

On-board Scale Compatibility

Some trucks may be equipped with on-board scale functionality which uses height sensors in the suspension to approximate the amount of payload in the vehicle. These systems measure the amount of suspension compression and estimate the amount of payload in the vehicle based on the known suspension stiffness. When using LOGIQ™ products (or any load leveling product), it is important to understand that the on-board scales will not provide accurate weight measurements and could indicate "zero" payload after the air suspension has been inflated even though there could be significant payload in the vehicle.

WARNING: AFTER INSTALLING LOGIQ™ PRODUCTS, DO NOT USE ON-BOARD SCALE FUNCTIONALITY IF EQUIPPED. SUCH SYSTEMS WILL NOT CORRECTLY MEASURE THE VEHICLE LOAD IF THE AIR SUSPENSION IS INFLATED.