



**PART # CB99**  
**Carrier Bearing Bracket**  
1999-2001 CHEVY 1500  
2001 CHEVY HD  
**INSTALLATION INSTRUCTIONS**



Rev. # 10-01

Please take the time to read these **INSTALLATION INSTRUCTIONS** and check the **Hardware Parts List** to be sure you have all the listed parts.

These installation instructions are prepared for the professional installer with the proper equipment, tools and experience in suspension systems and safety.

**Hardware Parts List:**

- 1- Carrier Bearing Bracket.
- 2- 3/8" x 3-1/2" Bolts w\ nuts and washers.

Vehicles with 2 piece drive shafts may experience drive line vibration at low speeds and will need to raise the carrier bearing.

The bearing is welded to a round cross member and will need to be cut off and moved up.

Cut stock bracket off cross member. Place new bracket on carrier bearing and position on cross member at the new location. Mark the center of the slotted hole and drill through cross member with a 3/8" bit.

Bolt bracket to cross member and to carrier bearing and tighten. You can adjust bracket up or down if needed.



Check out all the DJM products on the web [www.DJMSuspension.com](http://www.DJMSuspension.com)

Tech Line (310) 538-1583