

ROUGH COUNTRY

SUSPENSION SYSTEMS®

THANK YOU FOR PURCHASING A ROUGH COUNTRY PRODUCT. WE APPRECIATE YOUR BUSINESS!
IF YOU HAVE ANY QUESTIONS, PLEASE CALL 1-800-222-7023.

INSTALLATION INSTRUCTIONS

1. Using a 13mm socket, remove the 8mm bolt just to the outside of the visor. **See Photo 1.**
2. Using a 13mm socket, remove the 8mm bolt on the A-pillar. ****Caution** Bolt may fall behind plastic cover during removal. See Photo 2.**



3. Using the supplied 8mm x 70mm and the shorter supplied spacer, install the bolt through the grab bar and then through the spacer. Next, thread into the upper hole to the outside of the visor. **See Photo 3. Do not Tighten.**
4. Using the supplied 8mm x 100mm and the longer supplied spacer, install the bolt through the grab bar and the spacer. Now, thread the bolt into the hole on the A-pillar. **See Photo 4.**
5. Tighten both bolts with a 6mm Allen.
6. Repeat steps 1-5 on opposite side.



Visit us on the web @ www.roughcountry.com for your off road needs.

By purchasing any item sold by Rough Country, LLC, the buyer expressly warrants that he/she is in compliance with all applicable , State, and Local laws and regulations regarding the purchase, ownership, and use of the item. It shall be the buyers responsibility to comply with all Federal, State and Local laws governing the sales of any items listed, illustrated or sold. The buyer expressly agrees to indemnify and hold harmless Rough Country, LLC for all claims resulting directly or indirectly from the purchase, ownership, or use of the items.

