

ROUGH COUNTRY

SUSPENSION SYSTEMS

THANK YOU FOR PURCHASING A ROUGH COUNTRY PRODUCT. WE APPRECIATE YOUR BUSINESS!
IF YOU HAVE ANY QUESTIONS, PLEASE CALL 1-800-222-7023.

INSTALLATION INSTRUCTIONS

1. Using a 10mm socket, remove the (2) 6mm bolts as indicated.
See Photo 1 & 2.
2. Using the supplied 6mm bolts, install the (2) bolts through the grab bar threading into the upper hole as indicated.
See Photo 3. Do not Tighten.



3. Tighten both bolts with a 5mm Allen to 120 in-lbs of torque.
4. Repeat steps 1-4 on opposite side.



Visit us on the web @ www.roughcountry.com for your off road needs.

By purchasing any item sold by Rough Country, LLC, the buyer expressly warrants that he/she is in compliance with all applicable , State, and Local laws and regulations regarding the purchase, ownership, and use of the item. It shall be the buyers responsibility to comply with all Federal, State and Local laws governing the sales of any items listed, illustrated or sold. The buyer expressly agrees to indemnify and hold harmless Rough Country, LLC for all claims resulting directly or indirectly from the purchase, ownership, or use of the items.

