



baja designs
The Scientists of Lighting

Dodge Ram Fog Pocket Kit

1. Start by unplugging your factory fog lights.
2. Remove (3) 10mm bolts per side. The fog light assembly is now ready for removal. You will no longer need it.



3. Install the Baja Designs Squadrons onto the supplied brackets. **Please make it noted the direction of the Squadron brackets when installing them onto the lights.** We recommend Spot Beam on the inside and Driving/Combo or Wide Cornering on the outside.



4. Install the Baja Designs Brackets and Lights into the OEM location using the factory 10mm bolts.



5. Plug the supplied wiring adapter into the Baja Designs Lights then into your OEM Plug.
6. Your Install is now complete. Thank You for choosing Baja Designs: The Scientists of Lighting.