



ITEM NO.	PART NUMBER	QTY/Side
1	44-9106 OEM Polaris RZR Driver Side Mount	1
2	Squadron Assm	2
3	Stock Screw	3
4	20-1020 6mm Washer	4
5	20-1026 6mm oversized washer	2

#### Instructions:

1. Unbolt front grille shroud of the Polaris RZR.
2. Lean front grille shroud forward and remove stock headlight (3 bolts per side).
3. Use the stock 3 screws and supplied 6 washers (one on each side of the bracket, the two larger washers are to be used on the slotted end of the bracket) to bolt on RZR Bracket.
4. Install lights onto the bracket and use wiring harness to connect lights into stock plugs. The harness with green sticker and black diode on plug must be connected to passenger side wiring harness.  
NOTE: XP1000- White wire= Low beam, Yellow wire= High beam  
2015+ 900 & General- Red wire= Low beam, Blue= High beam
5. Change the stock 10amp headlight fuse in the fuse box with a 20amp fuse.
6. Adjust to optimize performance.
7. Reinstall front grille shroud.
8. After install and use, periodically check screws to ensure they are still securely tightened.