



NOTE: brackets and lights are oriented as if you are looking at the front of the vehicle

ITEM NO.	PART NUMBER	QTY.
1	44-7040 Can-Am Maverick(13-16) Renegade(11-16) DS Inside Mount	1
2	44-7041 Can-Am Maverick(13-16) Renegade(11-16) DS Outside Mount	1
3	44-7042 Can-Am Maverick(13-16) Renegade(11-16) PS Inside Mount	1
4	44-7043 Can-Am Maverick(13-16) Renegade(11-16) PS Outside Mount	1
5	20-1031 Hardware Pan Head Phillips 8-11 x 0.5	14
6	Squadron	4

Instructions:

1. First step in installing your new Can-Am headlight replacement kit is to remove the stock lights. To do this remove the small black triangle body panel from each outside corner of the vehicle. Next use a T30 torx and 10mm wrench to unbolt the 3 bolts on the outside of the vehicle. There are two more torx bolts under the hood directly in between the low and high beam light.
2. Once the headlight shell is removed, unscrew the stock lights from the headlight shell.
3. Next install your squadron series lights in the recommended orientation above onto the Can-Am adapter brackets. Please note for the two inner brackets it is easier to install the lights onto the Can-Am adapter bracket if the stock squadron bracket is left loose. Snug all the bolts leaving them just loose enough to adjust while they are on the vehicle.
4. Install the lights with the new Can-Am adapter brackets and bolt onto the vehicle. Use the plug and play wiring harnesses to connect your lights to the stock harness. The stock connectors have a green and blue wire. The blue wire will be your high beam lights and green will be the low beam. We suggest using the driving combo light as your low beam and spot as your high beam.
5. Adjust your lights to the position you prefer and either tighten them on the vehicle or you might find it easier to carefully remove the headlight shell and tighten the bolts.
6. Finally, tie up the wiring to prevent it from being caught in the moving parts of the vehicle.

BUILD SHEET

Can-Am, Maverick(13-16)/Renegade(11-16) Kit

- 44-7040 Can-Am Maverick(13-16)
Renegade(11-16) DS Inside Mount (x1)



- 44-7041 Can-Am Maverick(13-16)
Renegade(11-16) DS Outside Mount (x1)



- 44-7042 Can-Am Maverick(13-16)
Renegade(11-16) PS Inside Mount (x1)



- 44-7043 Can-Am Maverick(13-16)
Renegade(11-16) PS Outside Mount (x1)



- 60-0039 Connector, Universal
9006/9005/H10 to 2 pin Wea Pac (x4)



Misc. Hardware

- 20-1031 Hardware Pan Head Phillips 8-11 x 0.5 (x14)



- Note: Lights included come in the following variations:

- X2 Driving Combo Squadron-R Sports X2 Spot Squadron-R Sports

44-7044 "Sportsmen"

- X2 Driving Combo Squadron-R Pro X2 Spot Squadron-R Pro

44-7045 "Pro"

- X2 Driving Combo Squadron-R X2 Spot Squadron-R Racer Editions

44-7046 "Unlimited"

Checked By _____