



**baja designs®**  
*The Scientists of Lighting*

**Polaris XP Turbo (16-18)  
Hood Mount Instructions  
44-7073**



185 Bosstick Boulevard • San Marcos • CA • 92069

Phone 760-560-2252 • Fax 760-560-0383

info@bajadesigns.com • [www.bajadesigns.com](http://www.bajadesigns.com)



***baja designs***<sup>®</sup>  
*The Scientists of Lighting*

## **LIMITED LIFETIME WARRANTY**

Baja Designs proudly offers a LIFETIME WARRANTY against manufacturer's defect on all the products that we manufacture.

These are comprehensive warranties; other than the exclusions below – you're covered. If your LED or HID bulb burns out, you're covered. Additionally, cutting off our connector or changing your lenses does not automatically void your warranty.

### **Exclusions:**

Installation errors, abuse, misuse or crash damage. You must be the original owner of the product and can supply proof of purchase.

Baja Designs manufactures its own products as well as resells products manufactured by others. Baja Designs makes no express or implied warranties on products not manufactured by Baja Designs including without limitation any warranties or merchantability and fitness for a purpose. We will, however, pass on all warranties made by the manufacturer, who has sole responsibility for performing such warranties.

Baja Designs will pay the freight if your product is less than 90 days old, otherwise defective products must be returned to Baja Designs, Inc., freight prepaid. At our option, we will repair or replace items in question and return them at no charge. If the identical product is no longer available, we will replace with a similar product of equal value. Baja Designs Inc. will not be responsible for any indirect or consequential damages in connection with defective merchandise.

Items purchased through a Baja Designs authorized dealer must be returned through the dealer. Only available on LED auxiliary lights and product must be in sellable condition at MSRP. Product that has been damaged in any way after the original purchase date will be excluded from this guarantee.

### **Indemnification:**

**Buyer hereby acknowledges off-roading, racing and driving at night are dangerous activities and that the products and/or supplies purchased from Baja Designs are used in an inherently dangerous activity that may endanger life and limb; and in no event shall the seller, or seller's heirs and assigns, be held liable for consequential damages, nor shall seller's liability on any claim for damages arising out of or connected with the sale, delivery, or use of purchased products and/or supplies exceed the purchase price of the products and/or supplies**



**baja designs**  
The Scientists of Lighting

## **44-7073 Polaris XP Turbo (16-18) Hood Mount Instructions**

### **Tools Required**

T40 Torx bit and wrench

7/16 wrench

10mm socket and ratchet

1. Remove your Hood
2. Remove the 2 - T40 Torx screws and loosely mount the supplied L brackets as shown.



3. Bolt the S8 to the L brackets and tighten
4. Tighten the T40 screws





**baja designs**  
The Scientists of Lighting

5. Route wires around shroud and connect to harness supplied in kit



6. Using a 10mm socket and connect the negative and positive terminals of the wiring harness to the positive and negative terminals under the hood or directly to the battery underneath your seat. Do not connect the harness leads to the far left terminal (this can only take a small amount of amps)



7. Insert the S8 backlight extension into the empty slot on the harness and attach that to the FAR LEFT terminal post to enable the back light feature to come on with ignition.
8. Route the switch through the rubber boot on the firewall and mount it to the dash in the area of your choice.

Re-torque all the fasteners after 100 miles.  
Your install is now complete! Thank you for choosing Baja Designs.