



baja designs[®]
The Scientists of Lighting

**2019 Ford Ranger 20" OnX6 / S8
Lower grill kit Instructions
(44-7611, 44-7612)**



185 Bosstick Boulevard • San Marcos • CA • 92069

Phone 760-560-2252 • Fax 760-560-0383

info@bajadesigns.com • www.bajadesigns.com



baja designs[®]
The Scientists of Lighting

LIMITED LIFETIME WARRANTY

Baja Designs proudly offers a LIFETIME WARRANTY against manufacturer's defect on all the products that we manufacture.

These are comprehensive warranties; other than the exclusions below – you're covered. If your LED or HID bulb burns out, you're covered. Additionally, cutting off our connector or changing your lenses does not automatically void your warranty.

Exclusions:

Installation errors, abuse, misuse or crash damage. You must be the original owner of the product and can supply proof of purchase.

Baja Designs manufactures its own products as well as resells products manufactured by others. Baja Designs makes no express or implied warranties on products not manufactured by Baja Designs including without limitation any warranties or merchantability and fitness for a purpose. We will however, pass on all warranties made by the manufacturer, who has sole responsibility for performing such warranties.

Baja Designs will pay the freight if your product is less than 90 days old, otherwise defective products must be returned to Baja Designs, Inc., freight prepaid. At our option, we will repair or replace items in question and return them at no charge. If the identical product is no longer available, we will replace with a similar product of equal value. Baja Designs Inc. will not be responsible for any indirect or consequential damages in connection with defective merchandise.

Items purchased through a Baja Designs authorized dealer must be returned through the dealer. Only available on LED auxiliary lights and product must be in sellable condition at MSRP. Product that has been damaged in any way after the original purchase date will be excluded from this guarantee.

Indemnification:

Buyer hereby acknowledges off-roading, racing and driving at night are dangerous activities and that the products and/or supplies purchased from Baja Designs are used in an inherently dangerous activity that may endanger life and limb; and in no event shall the seller, or seller's heirs and assigns, be held liable for consequential damages, nor shall seller's liability on any claim for damages arising out of or connected with the sale, delivery, or use of purchased products and/or supplies exceed the purchase price of the products and/or supplies.



baja designs
The Scientists of Lighting

2019 Ford Ranger Grill light bar Instructions

Tools Required

- 21mm Socket wrench
- Standard screwdriver
- 7/16" wrench
- 7/16" Socket wrench

**Note: if your Ranger is equipped with a speed sensor in the middle of the lower grill opening, this kit won't fit and may effect the onboard vehicle safety system.

1. To begin, pry the center portions of the plastic fasters located on the underside of the lower grill opening. See image below. Pry the bottom portion of each plastic fastener to remove.



2. Gently pull on the lower grill opening's plastic cover near the locations shown below.





baja designs
The Scientists of Lighting

3. Once the cover is free, there are two plugs that must be disconnected. Set bumper cover aside.



4. With a Standard screwdriver (flathead), bend all the bumper cover mounting clips back to original condition. Before picture on left below, after on right.



5. Using 21mm socket wrench, remove OEM frame nut circled below, place bracket, and lightly tighten nut. Passenger side is pictured below. Repeat for driver's side.





baja designs
The Scientists of Lighting

6. Place the lightbar into the opening. Thread in the 1/4" hardware and lightly tighten with 7/16" socket wrench. The 7/16" wrench will help with the rearward mounts.



7. Once satisfied with the positioning of the light, tighten the 1/4" hardware, then tighten the large factory nuts from step 5.
8. With the plastic bumper cover near the mounting location, connect the safety sensor plugs and gently begin to press the cover back into the mounts. Work around the cover and refer to the image under step 2 for the mount locations.

Re-torque all the fasteners after 100 miles.

See the instructions supplied with the wiring harness to complete wiring needs.

Your install is now complete! Thank you for choosing Baja Designs.