

2014-21 TUNDRA XB LED TAIL LIGHTS INSTALL GUIDE

WARNING: By reading this document, you agree it is only to be used as an educational guide. Morimoto Lighting nor its dealers make guarantees on any finished results, nor are they to be held responsible for any damage, misuse, or personal injuries. If you are unable to clearly understand and adapt the information below, professional installation is recommended.

PACKAGE CONTENTS



2X TAIL LIGHT ASSEMBLIES

4X MOUNTING BOLTS

TOOLS REQUIRED

#1 PHILIPS SCREWDRIVER TORX T30 BIT OR DRIVER

IMPORTANT: If your vehicle is equipped with anything but OEM turn signals (full assemblies, LED bulbs, or otherwise) in the headlights or elsewhere: You may experience a hyper flash and/or problems with the sequential signal setting on these tail lights. This is not a defect in the tail light, and caused by un-matched impedance with your original vehicle settings.



INSTALLATION PROCESS

1. Prepare your tail lights for installation by installing the resistors. Use the provided Philips head screws to mount the resistors exactly like shown. NOTE: The driver side resistor must be mounted vertically and with only one screw to avoid contacting the tailgate strut.





Driver's Side

Passenger Side

2. Lower the tailgate. Remove the two (2) T30 torx bolts holding in each tail light (Image #1). Pull the tail lights back and away to remove from the truck (Image #2). NOTE: These factory bolts will NOT be reused!







Image #1

3. Disconnect the OEM connectors by pressing the release tabs then sliding the connector off.



4. Determine which style turn signals you would like from your tail lights. Connect red + green for sequential turn signals or red + yellow for standard on/off turn signals.





- 5. Install the tail light on to the truck. Install the provided shorter bolts and hand tighten.
- 6. Turn on the truck and go through all modes to confirm the tail lights function properly.
- 7. Enjoy your new Morimoto XB LED Tail Lights!

-END-

