

O9-18 DODGE RAM X3B THIRD BRAKE LIGHT INSTALLATION GUIDE

WARNING: By reading this document, you agree it is only to be used as an educational guide. Morimoto Lighting nor its dealers make guarantees on any finished results, nor are they to be held responsible for any damage, misuse, or personal injuries. If you are unable to clearly understand and adapt the information below, professional installation is recommended.

PACKAGE CONTENTS



TOOLS REQUIRED

#2 PHILIPS SCREWDRIVER

INSTALLATION PROCESS

1. Remove the 2 (two) Philips screws holding the brake light in place. Pull brake light away from vehicle.



2. Unplug the factory connector and remove the third brake light from the truck.



- 3. Installation is reverse of removal.
- 4. Turn on the truck and go through all modes to ensure proper functionality.

-END-