



CS-DD30-14-COILRETAINER
Dodge Dominator Coil Retainer, 2014+

Parts Checklist

- (Qty. 2) - Front Coil/Isolator Supports

Instructions

1. **This instruction is written as for those in process of installing the Dominator system; if you're installing just the coil isolator supports:** jack the truck up and support with appropriate jack stands. Disconnect the front brake line brackets from the rear of the coil buckets and top of the radius arm mounts to allow room to droop the axle and remove the coil springs. Disconnect the sway bar end links from the sway bar and swing it up and out of the way. Disconnect the frame side track bar bolt. Finally, remove the front shocks and droop the axle to remove the springs and factory coil isolators. This will leave you with the bare coil bucket.
2. Clean all surfaces that will be welded.
3. Test fit and tack-weld the Carli Supports into the buckets.
4. With proper fitment confirmed, fully weld the supports. Grind the weld so the joint is seamless, then prime and paint.
5. With the supports painted, continue to the next step in the Dominator instructions or, if just installing the supports, reassemble the front end.

