



CS-DLSM-14-F Dodge Dominator Lower Shock Mounts

Parts Checklist

- (Qty. 2) - Front Lower Shock Mounts, Mirrored
- (Qty. 2) - M14 x 80mm Bolts
- (Qty. 4) - M14 Washers
- (Qty. 2) - M14 Nylock Nut

Instructions

1. **This instruction is written as for those in process of installing the Dominator system; if you're installing just the lower shock mounts:** Jack the front of the truck up and support with the axle with suitable jack stands. Remove the wheels and tires for the Remove the front shocks and droop the axle to remove the springs and factory coil isolators. This will leave you with the bare coil bucket.
2. Remove the factory shock mounts from the axle. We used a Plasma Cutter to cut off the majority—followed by a flap disc to grind to the bare axle.



3. Grind a taper into the arced surface to prep it for installation to the axle tube.
4. The shock mount has a side specific index that will seat against the bottom the lower coil bucket bracket on the axle and the radius arm mount on the axle.



5. With the shock mount in place, weld the shock mount to the axle tube.
6. Move onto the next step in the Dominator instructions. If only installing the shock mounts — reassemble the front end.

