

Hellwig PRODUCTS.com

559-734-7451 800-367-5480 FAX 559-734-7460


INSTALLATION INSTRUCTIONS FRONT STABILIZER BAR 2010+ CAMARO

Thank you for purchasing a quality Hellwig Product.

PLEASE READ THIS INSTRUCTION SHEET COMPLETELY BEFORE STARTING YOUR INSTALLATION

1. Raise vehicle and place on jack stands. Make sure vehicle is secure and stable before proceeding to next step.
2. Remove driver's side front wheel.
3. Disconnect end links from sway bar. **Save hardware for reinstallation of new sway bar**
4. Remove nuts attaching bushings to subframe. **Save hardware for reinstallation of new sway bar**
5. Remove sway bar by maneuvering it out from the driver's side. It may be necessary to raise the engine to allow clearance for the sway bar to be removed from the vehicle. Consult factory service manual for correct procedure.
6. Install new sway bar using reverse of procedure to remove factory sway bar.
7. Lubricate D-bushings using supplied lubricant and install on sway bar with supplied U-plates.
8. Attach U-plates to subframe using factory hardware.
9. Attach end links to sway bar and tighten firmly.
10. Center sway bar on vehicle and attach collar clamps to sway bar inboard of the frame bushings to keep sway bar centered in use.
11. Bounce the vehicle. Check for clearance on all undercarriage components. Recheck your installation - check for clearance on wires, exhaust, fuel and brake lines.
12. After one week of driving check your installation. Recheck on a monthly regular basis thereafter.

ATTENTION INSTALLER: BE SURE THAT THE CUSTOMER RECEIVES THIS INSTRUCTION SHEET, ALL IMPORTANT NOTE CARDS AND THE WARRANTY FORM



Install collar clamps inboard of frame bushings to keep sway bar centered.