



Intake Kit Installation Instructions: Jeep cherokee (XJ) 91-01 I6-4.0L Stage-2 Air Intake

Accessories Available:




Restore Kits

- 90-50001 Blue Aerosol
- 90-50501 Blue Squeeze
- 90-59999 Pro Dry S™ Cleaner



Pre-filter 28-1008x



Replacement Air Filter:



Pro-5R™ 24-30018
Blue Media



Pro Dry S™ 21-30018
White Media


Note: Filter Cleaning and Re-oiling: When cleaning your aFe filter, be sure to use only aFe's "Restore Kit" (aFe P/N: 90-50001 blue oil aerosol, aFe P/N: 90-50501 blue squeeze bottle oil, aFe P/N: 90-59999 Pro Dry S™ cleaner only.) Pro Dry S™ cleaning: see cleaning instruction sheet 06-00074. For replacement part(s) or "Restore Kit" please call aFe sales/tech support @ 951-493-7100

Step 16



Insert tube in coupler. Place isolation mount in hole of housing.

Step 17



Attach 1/2" hose to crankcase engine side.

Step 18



Install flat/wavy washers and nut to isolation mount. Tighten both sides with 10mm socket or wrench.

Step 19



Tighten all clamps using 5/16" nut driver.

Step 20



Install air filter on tube and tighten using 5/16" nut driver.

Step 21



NOTE: Retighten all connections after approximately 100-200 miles. Place the included CARB EO sticker on or near the device on a smooth, clean surface. EO identification label is required to pass the smog inspection.

Install trim seal on housing.

Your installation is now complete. Make sure you tighten all clamps and check all electrical connections periodically. Thank you for choosing aFe!