

Einbauhinweise / Installation Instructions

Hinweis Nr./ Instruction No.	Federwegbegrenzer Vorderachse / Front axle bumpstop	Erstellt am/ Date	18.03.2015
---------------------------------	---	----------------------	------------



EINBAUHINWEISE

**Vor der Fahrwerksmontage ist folgendes
in jedem Fall zu beachten:**

- Das Gutachten muss mit den technischen Daten des Fahrzeugs übereinstimmen (VA- und HA-Last, Leistungsbereich, Fahrzeug Typ Nr. und ABE EG Nr.).
- Die Fahrwerkskomponenten müssen mit dem Gutachten übereinstimmen (Feder - und Federbeinkennzeichnung).

Bei der Entwicklung von ST Fahrwerken wird auf eine möglichst einfache Handhabung geachtet. Sofern dies nachfolgend nicht abweichend beschrieben ist, werden alle Fahrwerkselemente gemäß den Richtlinien der Fahrzeughersteller aus- und eingebaut. Irrtümer und Änderungen vorbehalten.

INSTALLATION INSTRUCTIONS

**Before you start installation work,
please read the following carefully:**

- Ensure that the TUEV certificate matches the vehicle specifications (front and rear axle weights vehicle identification number (VIN)) etc...
- The suspension components must match the suspensions application specifications (springs and shock/struts identification numbers).

ST coilovers are designed for easy installation. If not otherwise stipulated in these instructions, all suspension components are installed and removed in accordance with the manufacturer's specifications for installing and removing standard springs and damper components. At the time of printing all instructions and specifications are correct.



Einbauhinweise / Installation Instructions

Hinweis Nr./
Instruction No.

Federwegbegrenzer Vorderachse / Front axle bumpstop

Erstellt am/
Date

18.03.2015

Vorderachse/ Front axle:

Original Anschlagelement muss auf eine Länge von 60mm gekürzt werden.

Cut the OEM bump stop to a length of 60mm / 2,4".

