



ITEM NO.	PART NUMBER	QTY.
1	44-7586 OEM Chevy 1500 2500 & 3500 30inch OnX6&S8 Grille	1
2	44-7587 OEM Chevy 1500 2500 & 3500 30inch OnX6&S8 Grille	1
3	44-7594 Chevy 2500 3500 30inch Onx6 S8 Grille Support Mount (15-16)	2
4	20-1287 1-4-20 0.875inch bolt	6
5	20-1286 1-4-20 Nylock Nut	6
6	20-1282 1-4 inch flat washer	12

Instructions:

1. First step to installing your new 30inch S8/OnX6 grille kit is to open the hood and remove the large black cover above the radiator. Next remove the 4 bolts holding the grille onto the vehicle (some models may have more bolts below). If you are unsure how your grille comes off you may need to do additional research to learn the proper way to remove it.
2. Next, attach the brackets to your light bar in the orientation shown above.
3. Now hold the light bar and mounts up to the truck and attach the brackets to the two square tube support beams in front of the radiator. The rear support bracket has four holes but only one is used as seen in the picture above.
4. Hold the grille up to the truck to check that the light is centered and level and then reattach the grille.

BUILD SHEET

44-7588

Chevy, 1500/2500/3500 30inch Onx6/S8 Grille Mount Kit (15-16)

44-7586 OEM Chevy 1500, 2500 & 3500 30inch OnX6 & S8 Grille Mount DS 15-16 (x1)

44-7587 OEM Chevy 1500, 2500 & 3500 30inch OnX6&S8 Grille Mount PS 15-16 (x1)



44-7594 Chevy 1500, 2500 & 3500 30inch Onx6 S8 Grille Support Mount (15-16) (x2)



Misc. Hardware

20-1287 1-4-20 0.875inch bolt (x6) (HW56)



20-1286 1-4-20 Nylock Nut (x6) (HW50)



20-1282 1-4 inch flat washer (x12) (HW64)



Checked By _____