

# Traxda

## #906060 Toyota Highlander Installation Instructions

### Front

1. Lift truck, place on jack stands or 2 post lift

2. Remove windshield wiper cowl

3. Remove upper strut nuts

4. Remove sway bar links

5. Remove ABS wire guide

6. Remove bolts on lower strut at spindle

7. Remove strut from vehicle



8. Place Traxda part on strut and bolt on



9. Re install strut

10. Install sway bar link brackets onto strut. We are using the bracket to make the link shorter, to compensate for the additional strut length.



## Rear

1. Remove 3 nuts holding upper shock
2. Mark inside lower control arm nut to preserve alignment
3. Loosen inside control arm bolt
4. Remove sway bar link bracket at arm
5. Remove outside control arm bolt and let spring come out
6. Remove 3 bolts holding spring perch in

7. Install Traxda spring plate where spring perch was mounted, with spring perch mounted below.



9. Install shock bracket



10. Re install spring and reattach control arm bolt
11. Re install shock

## ALIGNMENT

Align to stock settings. May need camber bolt kit for front.