

CFMOTO Uforce 1000XL REAR HIGH MOUNT LIGHT BAR MOUNT

Thank you for choosing Rough Country for all your vehicle needs.

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.

If question exist, please call us @1-800-222-7023. We will be happy to answer any questions concerning this product.

Check all fasteners for proper torque. Check to ensure for adequate clearance between all components.

Periodically check all hardware for tightness.

KIT CONTENTS:

2 - Light Bar Bracket
96109BAG1

TOOLS NEEDED:

13mm Socket or Wrench

HARDWARE INCLUDED:

96109BAG1
6 - 8mm x 15mm Bolt



INSTALLATION INSTRUCTIONS

1. Attach the bracket to the rear cage of the vehicle using the supplied 8mm bolts. Tighten with a 13mm wrench. **See Photo 1.**
2. Attach the light bar onto the driver and passenger side brackets using the hardware included with the light.
3. Wire light bar according to instructions included in light bar box.



POST INSTALLATION INSTRUCTIONS

1. Check all fasteners for proper torque. Check to ensure for adequate clearance between all rotating, mobile, fixed, and heated members. Verify clearance between exhaust and brake lines, fuel lines, fuel tank, floorboards, and wiring harness.
2. Check electrical wiring to ensure adequate clearance between all rotating, mobile, fixed, and heated members.

By purchasing any item sold by Rough Country, LLC, the buyer expressly warrants that he/she is in compliance with all applicable, State, and Local laws and regulations regarding the purchase, ownership, and use of the item. It shall be the buyers responsibility to comply with all Federal, State and Local laws governing the sales of any items listed, illustrated or sold. The buyer expressly agrees to indemnify and hold harmless Rough Country, LLC for all claims resulting directly or indirectly from the purchase, ownership, or use of the items.

