

INSTALLATION MANUAL


RIVAL

UP-TO-DATE
MANUAL

PRODUCT: FRONT CROSMEMBER FOR 2333.9571.2.6

APPLICATION: TOYOTA TACOMA (2024-PRESENT)

PART NO: 2333.9571.2.6.RK



CAUTION!

To reduce the risk of serious injury or damage to property: Before you start installing and using this product, read the full instructions, pay special attention to the conditions of safe use and recommendations for installation! When installing or maintaining this product, it is necessary to use protective goggles. Check the integrity of the installed components and torque all hardware every 250 miles (400 kms). Discontinue use if there is any damage to the structure or fasteners!

NOTICE

Skid plates are supplemental protection. We cannot guarantee protection against all possible damage from impacts. When driving, be careful of objects and terrain that may damage sensitive parts of the vehicle.

FRONT CROSMEMBER

RIVAL

Part number: 2333.9571.2.6.RK

Suited to vehicle: Toyota Tacoma 2.4, 2.4 Hybrid; AT; 4WD, RWD (2024-PRESENT)(except TRD Offroad, TRD Pro and Trailhunter)

Material: Steel



SAFETY NOTICE

- * The RIVAL skid plate is designed to complement the use and design of the specified vehicle under conditions underlined by the vehicle manufacturer.
- * While driving the vehicle at any speed, collision with another vehicle, animal or object must always be avoided.
- * Following any collision with another vehicle, animal or object, the RIVAL skid plate and the vehicle must be inspected by a specialized or suitably qualified vehicle technician for possible damage to the components and assemblies in order to confirm suitability for further use of the vehicle.
- * It is strongly recommended that you do not operate a vehicle with a damaged skid plate or its components. In the case of damage, please contact the nearest RIVAL dealer. A damaged vehicle or skid plate is extremely dangerous and should be avoided at all cost.
- * We recommend using a funnel when changing the oil to prevent spills and ensure a clean process.

INSTALLATION NOTICE

- * The RIVAL skid plate must be mounted to the vehicle according to this installation manual.
- * Personal safety during the installation process must be adhered to at all times.
- * Do not install this skid plate on vehicle models other than those listed in this manual.
- * Estimated time for installation: 1 hour.
- * It's good practice to use a tap on all included hardware and bracketry to ensure ease of final assembly.



REQUIRED TOOLS

- * Basic tool kit
- * Torque wrench

TORQUE SETTING

- * M8 - 24 N·m (17.7 lb/ft)

*If your Tacoma doesn't have factory front crossmember.



1. Mounting bracket.....Qty 1

A



B



C



A. Bolt M8x1.25x110.....Qty 2
B. Washer M8.....Qty 4
C. Nut M8x1.25.....Qty 2




Fig. 1

1. Secure crossmember (item 1) using M8x110 bolts, M8 washers and M8 nuts (items A, B, C) as shown in Fig. 1.

***Once all hardware is installed, check alignment and torque all hardware.**

2. Proceed to installation of skid plate part #2333.9571.2.6