



WARNING: This product contains a chemical known to the State of California to cause Cancer and Reproductive Harm. For more information, go to www.P65Warnings.ca.gov.

2021-2026 FORD RAPTOR 2WD/4WD REAR WHEEL WELL LINER

PLEASE READ INSTRUCTIONS CAREFULLY BEFORE STARTING THE INSTALLATION.

NOTE: FOR EASIER INSTALLATION, REMOVE THE TIRE.

INCLUDED IN HARDWARE KIT:

1.



Driver Side & Passenger
Side Liner
1 pr

2.



U Clip
4 pcs

3.



Truss Head Screw
4 pcs

TOOLS NEEDED:

Gloves
7mm Socket
Pry Tool
#2 Phillips Screwdriver

BEFORE YOU BEGIN:

Please clean the interior panels of the rear wheel well.

Each Wheel Well Liner is marked at the top dead center (inside) with the side of the vehicle it should be installed on. The marking may be faint, but look for an "DS" (Driver Side) or an "PS" (Passenger Side) in this location:



REAR WHEEL WELL LINER INSTALLATION



Using a 7mm socket, remove and retain 8 factory bolts from the fender flare around the edge of the wheel well.

NOTE: The factory flare will not be removed.



Factory fastener locations.



Install 2 supplied "U" Clips over factory holes at back of wheel well, in locations indicated in next Step. Flat side of clip will face out when clip is installed.



"U" Clip locations.



Slide the Rear Wheel Well Liner behind wheel at rear of vehicle. It is helpful to tilt the liner at a 45-degree angle at front of wheel and then straighten it out once it's behind the wheel.



Tuck edge of Rear Wheel Well Liner between sheet metal lip of wheel well and edge of factory flares, sandwiching the Wheel Well Liner Between the two.



Use a Pry Tool to assist in seating the edge of the Wheel Well Liner along the entire edge.



Start a supplied Truss Head Screw through each hole in back of wheel well liner and into clips installed in Steps 3-4. Tighten both screws.



Reinstall 8 factory fasteners removed in Steps 1-2.



Installation is complete. Repeat for other side.