



KRYPTONITE

KR175 DEATH GRIP IDLER SUPPORT INSTALLATION

1. Remove the front heat shield, set it aside.
2. Disengage the idler arm by loosening the large nut at the bottom end of the OEM unit, then separate using a large mouth tie rod puller tool.
3. Remove the nut, lock washer, and idler arm, set aside the idler arm and hardware, next remove idler support hardware
4. Install your new Kryptonite Idler Support using the supplied 22mm Hardware (3.5" M14x2).
5. Reassemble the idler arm to your new Kryptonite Idler Support using new lock washer and nut. **Torque to 100 ft-lbs.**
6. Take this time to ensure the centerlink is sitting level by manipulating the support in the frame pocket, then torque the support hardware to **100 ft-lbs.** Torque the Idler arm to the centerlink to **46 ft-lbs.**
7. Have a professional alignment performed after replacement or modification of any steering and suspension component.



**Register your parts
here**



**Warranty Information
can be found here**

 **FOLLOW US**
@kryptoniteproducts

KRYPTONITEPRODUCTS.COM