



# **KRYPTONITE**

## **FORD SUPER DUTY WHEEL BEARING INSTALLATION**

- **APPLY HIGH TEMP BEARING GREASE**
- **TO THE O-RING BEFORE INSTALLATION**
  - **SPINDLE BOLTS: 133 ft-lbs**
  - **CALIPER BOLTS: 166 ft-lbs**

**CONTINUED ON BACK**

**WHEEL STUDS: 140-155 lb-ft  
(VARIES BASED ON MODEL YEAR/  
WHEEL MANUFACTURER)**



 **FOLLOW US**  
@kryptoniteproducts

**KRYPTONITEPRODUCTS.COM**