



KRFDSW1 SWAY BAR RELOCATION BLOCK

INSTALLATION INSTRUCTIONS

1. With the vehicle in Park on a clean level surface, remove the sway bar from the frame. You can support the sway bar with a strap if you are working alone.
2. Take your Kryptonite relocation blocks and install them onto the frame with the threaded bolt holes closest to the front of the truck. Torque to **37 lb-ft**.
3. With the relocation blocks installed, reinstall the sway bar to the blocks with the provided hardware. These will be torqued to **37 lb-ft** as well.

← Front of vehicle



Front of vehicle →



● Torque to 37 lb-ft ⬡ Torque to 37 lb-ft



Register your parts here.



 FOLLOW US
@kryptoniteproducts

KRYPTONITEPRODUCTS.COM