



KRYPTONITE
HARD CORE STEERING • SUSPENSION PRODUCTS

Fox Steering Stabilizer

KRFS001-K07

Removal:

Step 1 - Park on a level surface and chock rear tires. Raise the front of the truck and support the axle with jack stands.

Step 2 - Unbolt and take off the original steering damper and any associated brackets.

Installation:

Step 1 - Install the provided bracket onto the frame of the truck. Torque to 55 ft-lbs.



Step 2 - Bolt the hex clamp onto the drag link and torque the 4 Allen bolts to 10 ft-lbs.



Step 3 - The steering stabilizer will be installed with the body towards the passenger side. Using the provided hardware, torque to 67 ft lbs.

Step 4 - The rod end side of the stabilizer will be bolted onto the drag link adapter bracket using the provided tapered stud and nuts, torque to 67 ft lbs.



Step 5 - Turn the steering wheel fully from lock to lock to verify proper clearance and operation. Ensure the stabilizers do not bottom out or overextend at either extreme, and adjust the clamp positions as necessary to achieve proper travel.

⚠ IMPORTANT SAFETY & LEGAL INFORMATION

Installation should be performed by a qualified technician. Improper installation may result in vehicle damage, loss of control, serious injury, or death.

Always support the vehicle securely with jack stands. Never rely on a jack alone.

Verify all components are installed correctly and torqued to specification before operating the vehicle. After installation, inspect suspension and steering components and check for proper clearance through full travel.

Re-torque all hardware after initial use and periodically thereafter.

User assumes all responsibility for compliance with local laws.

Manufacturer is not responsible for damage or injury resulting from improper installation, misuse, or modification.

By installing this product, the user accepts all risk and liability associated with its use.