



**KRYPTONITE**

HARD CORE STEERING + SUSPENSION PRODUCTS

**Polaris XP Death Grip Ball  
Joint Reinforcement Bolt Kit**



- Prior to reinstalling the wheel/tire combo, a couple pumps of grease can be added to the ball joints. We recommend Ultra Duty Chevron EP2 be used in these ball joints. A synthetic NLGI #2 high pressure grease can substituted if you have something other than Chevron on hand.
- Replace the OEM ball joint hardware on the knuckle with the upgraded hardware. You will now be able to increase the clamping force on the ball joint studs by 34% over OEM.
- Snug the bolts and get the vehicle on the ground under its own weight. At that time, you will torque the new hardware to 55 Ft/Lbs.

***KRYPTONITEPRODUCTS***.COM