



KRYPTONITE

KR6344 Upper Ball Joint Installation

1. You can remove your OEM upper control arm from the vehicle and secure the arm on a work bench or attempt to remove the rivets with the control arm still on the truck. You can use a grinder or air chisel to remove the rivets.
2. Once cut, use a punch and hammer to completely remove the remaining rivet pieces. This is going to free the OEM ball joint from the arm.
3. Now that the stock ball joint has been removed. You may need to remove any burrs from the top side of the arm where the air chisel might have marred the surface.
4. With the arm cleaned up you will now install your new Kryptonite upper ball joint using the provided hardware. You will torque the new ball joint hardware to **22 lb-ft**.
5. Reinstall or reassemble that side of the truck and repeat steps 1-4 on the other side.





Cleaned up, ready
for ball joint



Install hardware



Torque to **22 lb-ft**



View Full Installation

Video here



Scan to register

your parts



 **FOLLOW US**
@kryptoniteproducts

KRYPTONITEPRODUCTS[®].COM