

ROUGH COUNTRY

SUSPENSION SYSTEMS®

9214195A0



WARNING: This product contains a chemical known to the State of California to cause Cancer and Reproductive Harm. For more information, go to www.P65Warnings.ca.gov.

2007-2018 JEEP JK 4 DOOR REAR INNER WHEEL WELL LINER

**PLEASE READ INSTRUCTIONS CAREFULLY BEFORE STARTING THE INSTALLATION.
NOTE: FOR EASIER INSTALLATION, REMOVE THE TIRE.**

**IMPORTANT NOTE: THESE INNER WHEEL WELL LINERS ARE DESIGNED TO BE USED WITH
ROUGH COUNTRY'S HIGH CLEARANCE FLAT FENDER FLARE KIT (PART 99037).**

THESE PARTS WILL NOT WORK WITH FACTORY FLARES.

**IF YOU HAVE ANY OTHER AFTERMARKET OR OE FENDER FLARES, SOME MODIFICATION
MAY BE NECESSARY TO COMPLETE THE INSTALL.**

INCLUDED IN HARDWARE KIT:

1.



Driver Side & Passenger Side Liner
1 pr

2.



Plastic Retainer
8 pcs

TOOLS NEEDED:

Gloves
Awl
Pliers (optional)

Pry Tool
4mm Allen Wrench



FACTORY FLARE REMOVAL AND WHEEL WELL LINER INSTALLATION



1
Aftermarket flare removal may differ. For factory flares, use a pry tool to remove three plastic retainers at front of wheel well. Use pliers if needed.



2
Remove three plastic retainers at rear of wheel well in same manner.



3
Starting at front of factory flare, pull flare firmly away from vehicle. Internal clips will snap and break.



4
Once flare is removed, use a pry tool or pliers to remove any remaining factory clips.



5
Slide the Rear Inner Wheel Well Liner behind the wheel.



6
Use an awl to help align fastening holes. Install four supplied Plastic Retainers through holes in Wheel Well Liner and into holes in wheel well.



Hole locations for Plastic Retainers.



This is the point where you will install your High Clearance Flat Fender Flare Kit (Part 99037) to instructions provided in that kit.



Completed Wheel Well Liner and Flare 99037 installation. Repeat for other side.