

Sway Bar End Link Kit

Colorado/ Canyon | 2015-2021

Part #: 121635

Rev. 031126



491 W. Garfield Ave., Coldwater, MI 49036 • Phone: 517-279-2135

Web: www.bds-suspension.com • E-mail: tech-bds@ridefox.com

SAFETY WARNING

BDS Suspension Co. recommends this system be installed by a professional technician. In addition to these instructions, professional knowledge of disassembly/ reassembly procedures and post installation checks must be known.

INSTALLATION INSTRUCTIONS

1. Remove old sway bar end links by loosening and removing (4) 7/16" nylock nuts.
2. New sway bar end links will be installed in same manner as the old were removed.
3. Install new sway bar links (911122) with (8) washers and (8) bushings (4805G) as shown. Orient link with machined flat closest to lower control arm. Attach with (4) 7/16" nylock nuts and 7/16" washers (BP #682). See Figure 1.
4. Tighten the new 7/16" nylock nuts until 1/8" of the link rod thread is exposed through the lock nut on both ends. **DO NOT EXCEED THE SPECIFIED TIGHTENING REQUIREMENT, AS OVERTIGHTENING MAY RESULT IN HARDWARE DAMAGE.**

Box Kit		
Part #	Qty	Description
911122	2	Sway Bar Link
4805G	8	Small Stem Bushing
682	1	Bolt Pack
	8	7/16" USS Washer
	4	7/16"-14 Nylock Nut

FIGURE 1

