



How to:

Switch DRL from white to amber on a 14-18 Chevrolet Silverado Nova or Luxx series headlights



This guide provides a detailed, step-by-step process for converting your DRL from white to amber.

DO NOT USE DIELECTRIC GREASE / REMOVE ANY DEBRIS OR ANY PRE-EXISTING GREASE OR WEATHER SEALANT

Contents

Tools needed:

No tools needed

How to: Switch DRL from white to amber on a 14-18 Chevrolet Silverado Nova or Luxx series headlights

- Start by flipping the light onto its back, then locate the upper weather cap.



- Once located, twist the cap off to access the interior of the light.



How to: Switch DRL from white to amber on a 14-18 Chevrolet Silverado Nova or Luxx series headlights

- With the light now open, locate the two single-wire plugs inside, they should be easily visible.



- Simply connect the two plugs to activate the amber DRL.



How to: Switch DRL from white to amber on a 14-18 Chevrolet Silverado Nova or Luxx series headlights

- Once complete, ensure the light is properly sealed and tightened. Repeat the process on the other side and the switch is now complete.

