Polaris Pro XP (20-On) OnX6 Roof Mount kit
44-7175, 44-7176

LIMITED LIFETIME WARRANTY

Baja Designs proudly offers a LIFETIME WARRANTY against manufacturer's defect on all the products that we manufacture.

These are comprehensive warranties; other than the exclusions below – you're covered. If your LED or HID bulb burns out, you're covered. Additionally, cutting off our connector or changing your lenses does not automatically void your warranty.

Exclusions:

Installation errors, abuse, misuse or crash damage. You must be the original owner of the product and can supply proof of purchase.

Baja Designs manufactures its own products as well as resells products manufactured by others. Baja Designs makes no express or implied warranties on products not manufactured by Baja Designs including without limitation any warranties or merchantability and fitness for a purpose. We will, however, pass on all warranties made by the manufacturer, who has sole responsibility for performing such warranties.

Baja Designs will pay the freight if your product is less than 90 days old, otherwise defective products must be returned to Baja Designs, Inc., freight prepaid. At our option, we will repair or replace items in question and return them at no charge. If the identical product is no longer available, we will replace with a similar product of equal value. Baja Designs Inc. will not be responsible for any indirect or consequential damages in connection with defective merchandise.

Items purchased through a Baja Designs authorized dealer must be returned through the dealer. Only available on LED auxiliary lights and product must be in sellable condition at MSRP. Product that has been damaged in any way after the original purchase date will be excluded from this guarantee.

Indemnification:

Buyer hereby acknowledges off-roading, racing and driving at night are dangerous activities and that the products and/or supplies purchased from Baja Designs are used in an inherently dangerous activity that may endanger life and limb; and in no event shall the seller, or seller's heirs and assigns, be held liable for consequential damages, nor shall seller's liability on any claim for damages arising out of or connected with the sale, delivery, or use of purchased products and/or supplies exceed the purchase price of the products and/or supplies

Polaris Pro XP Roof Mount Kit

Tools Required

- 7/16" wrench
- T40 Torx bit
- 10mm Socket wrench
- 4mm Allen wrench

1. Remove the two T40 Torx bolts circled in the picture. Repeat for opposite side. Place roof spacers aside, they will be used again.

Roof spacers under each bolt

2. Under the roof, slide out the four OEM U-nuts that the T40 bolts from step 1 thread into. Replace with the provided ¼"-20 U-nuts.

3. Thread the ¼" hardware from the OnX6/S8 hardware bag through the roof mounting brackets and into the light. Place the light above the mounting locations. Thread the ¼" roof hardware through the washers, bracket, roof spacers, roof, and U-nuts to mount the light. Repeat for all four roof mounts.

¼" OnX6 hardware

Roof hardware

Passenger Side   Driver Side

4. Open the compartment above the dash in the middle of the vehicle. Pull up on both arrowed tabs to remove tray. Place it to the side.

5. With the 10mm wrench, remove the negative battery lead (black arrow). Remove cover over the positive lead (white arrow) and then remove the lead. Place positive lead of the wiring harness over the positive battery lead and tighten. Replace Positive lead cover. **Important: Hold off on attaching the negative ring terminal of the harness for now.** Run the light connector lead through the starred passthrough grommet.

Negative battery lead

Positive battery lead

Passthrough grommet

*Inside Dash Compartment

6. Still looking through the top of the dash compartment, reach in and pop out the cover in the desired switch location. Drill a ¾" hole in the cover. Remove switch from wiring harness, note wire configuration, place switch in the cover, reconnect wires, and snap cover back into location.


*Inside Dash Compartment

Switch cover popped out

7. Tie up any excess harness inside the dash compartment safely away from other wires, or sharp objects. Replace the dash compartment tray and close the lid. Route the light plug lead from the firewall to the underside of the passenger side cage tube.

8. The dashed line shows where the rubber cover can be moved to route the harness through.

9. Route the light plug lead from the bottom of the passenger side cage tube up to the roof along the roll bar as shown by the arrow. Plug in the light and tie the entire harness away from any sharp, hot, or rotating components.

10. With the 10mm socket wrench, attach the negative ring terminal to the ground post from step 5. Turn on the light, adjust the OnX6 hardware and tighten.

Passthrough grommet in passenger side wheel well.

Passenger side cage tube

Alternate harness routing:

1. If the installer has tools for removing the Weather Pack connector, the harness can be routed inside the passenger side frame tube. The opening is arrowed on the right.

2. The exit is on the passenger side cage tube adjacent to the front crossmember.

3. Plug location A is ground (-), B is power (+) on the connector.

Re-torque all the fasteners after 100 miles.

Your install is now complete! Thank you for choosing Baja Designs.