

# BOOST TANK

---

## Installation Instructions *Rev.01*

---

**READ INSTRUCTIONS THOROUGHLY AND COMPLETELY BEFORE INSTALLATION.**

**INSTALLATION BY A CERTIFIED PROFESSIONAL MECHANIC IS HIGHLY RECOMMENDED.**

**LOGIQ™ IS NOT RESPONSIBLE FOR ANY DAMAGE OR FAILURE RESULTING FROM IMPROPER INSTALLATION.**

### **Warranty**

LOGIQ™ provides a limited lifetime warranty to the original purchaser of products, that the product be free from defects in workmanship and materials when used on cars and trucks as specified by LOGIQ™ and under normal operating conditions. This warranty is subject to the requirements and exclusions set forth in the full Limited Warranty and Return Policy that is available at [logiqair.com/warranty](http://logiqair.com/warranty). Air compressors are a wearing component and are covered by a 2-year warranty from the date of purchase. The warranty does not provide coverage for abuse, operation in a manner not consistent with the product's design, or damage resulting from exposure to the elements.

## Tools Required:

1/2" Wrench  
15 mm Wrench  
1/2" Socket  
9/16" Socket  
6 mm Hex Bit Socket  
Socket Driver & Torque Wrench  
Air Line Cutter (or Razor Blade)  
Cut Off Wheel (optional)

## Kit Includes:

(1) Boost Tank with 3/8" PTC fitting installed

(2) Inner Frame Brackets  
(2) Outer Frame Brackets

(2) 3/8"-16 Rounded U-Bolts

(4) 5/16"-18 x 5" Hex Bolt

(4) 5/16" Flat Washer

(4) 5/16"-18 Nylock Flanged Nut



(4) 3/8"-16 Nylock Flanged Nut

(1) 3/8" PTC Elbow Fitting

(4 ft) 3/8" Air Line

(8) Zip Ties


## Step 1: Mounting




- The Boost Tank is designed to be mounted outboard of the passenger side frame rail either in front (1) or behind (2) the AirIQ™ System. Many other locations may be chosen as long as the supplied 4 ft of air line reaches the AirIQ™ inlet port.
- Find the target location on the frame where the Boost Tank fits best and will not come in contact with any other objects on the vehicle.
- Determine the best location for the Frame Brackets to avoid contact with any plumbing or wiring. Mark the Boost Tank for where each of the frame brackets will fall.
- Mount the Frame Brackets to the tank using the supplied U-bolts at the locations marked above. **Snug the U-bolt nuts evenly, then torque to 6 lb.ft.**

## Step 1 (Continued): Mounting

If mounting to a narrow frame (less than 3.25" thick), orient the Inner Frame Brackets with the legs of the "C" pointed **TOWARD** the frame. If mounting to a thick frame (greater than 3.25" thick), orient the inboard mounting brackets with the legs of the "C" pointed **AWAY** from the frame.





Use the mounting holes that are closest to the frame height. Then cut the excess material from the bottom of the mounting brackets (paint exposed metal to avoid corrosion). **Torque all mounting hardware to 13 lb. ft.**



## Step 2: Plumbing

With your AirIQ™ system depressurized, use a 6 mm hex socket to remove the plug from the port labeled “IN”. Install the supplied 3/8” PTC elbow back into the port labeled “IN” with a 15 mm wrench and torque to **4.5 lb.ft.**

**!** **CAUTION:** Removing fittings from a pressurized system may cause bodily harm. If system was already pressurized, see “Tank Drain” section of AirIQ™ Instructions for depressurization procedure.



Route the supplied 3/8” air line from the 3/8” PTC elbow (above) to the 3/8” PTC Boost Tank fitting. Use the supplied zip ties to properly secure the air line while avoiding hot exhaust and sharp edges. Use the air line cutter supplied with your AirIQ™ system, or a sharp razor blade to make clean square cuts to the air line.

Note - This 3/8” air line may be tee'd to auxiliary pneumatic devices if desired (air horns, lockers, tire fill fittings, etc). Confirm that your auxiliary devices are rated for a maximum pressure of 150 psi. Be aware that draining the tank pressure more than 20 psi below the air spring pressure will cause the air springs to deflate.

**!** **WARNING:** The air line included with your AirIQ™ System is rated for a maximum temperature of 93C (200F). If routed too close to hot exhaust components, the air line may rupture causing the air suspension system to become inoperable.

**!** **CAUTION:** Improper air line cutting can cause permanent damage to the seals of your fittings which will result in air leaks.

## Step 3: Operation / Maintenance

**Operation** - Refer to the “AirIQ™ Installation Instructions” for system setup and operation with the Boost Tank.

**Maintenance** - Moisture may accumulate inside of the Boost Tank when not using a desiccant air dryer system. The moisture may be drained from the Boost Tank on occasion by first depressurizing the system (see “Tank Drain” section of AirIQ™ Instructions) then removing the Boost Tank from the vehicle and pointing it toward the ground to drain.

## Warnings and Disclaimers

### Safety Warnings

#### **MISUSE OF THIS PRODUCT COULD LEAD TO INJURY OR DEATH.**

Suspension systems or components that enhance the on and off-road performance of your vehicle may cause it to handle differently than it did from the factory. Extreme care must be used to prevent loss of control during abrupt maneuvers.

Always operate your vehicle at reduced speeds to ensure your ability to control your vehicle under all driving conditions. Failure to drive safely may result in serious injury or death.

Driver and passengers must **ALWAYS** wear seat belts, avoid quick sharp turns and other sudden maneuvers. LOGIQ™ does not recommend the combined use of suspension lifts, body lifts, or other lifting devices.

You should never operate your vehicle under the influence of alcohol or drugs.

Constant maintenance is required to keep your vehicle safe. Thoroughly inspect your vehicle before and after every off-road use.

It is the responsibility of the retailer and/or the installer to review all state and local laws, with the end user of this product, related to bumper height laws and the lifting of their vehicle before the purchase and installation of any LOGIQ™ products.

Raised vehicles have altered viewing angles than stock vehicles. This can lead to larger or different blind spots than the driver is accustomed. It is the responsibility of the driver to be aware of this and check their surroundings at all times while the vehicle is in motion and immediately prior to operating vehicle. Failure to do so can lead to damages, injury, or death.

### Installation Warning

All steps and procedures described in these instructions were performed while the vehicle was properly supported on a two post vehicle lift with safety jacks.

Use caution during all disassembly and assembly steps to ensure suspension components are not over extended causing damage to any vehicle components and parts included in this kit.

Included instructions are guidelines only for recommended procedures and are not meant to be definitive. Installer is responsible to insure a safe and controllable vehicle after performing modifications.

LOGIQ™ recommends the use of an OE Service Manual for model/year of vehicle when disassembly and assembly of factory and related components.

Unless otherwise specified, tighten all bolts and fasteners to standard torque specifications listed within the OE Service Manual.

Suspension components that use rubber or urethane bushings should be tightened with the vehicle at normal ride height. This will prevent premature wear or failure of the bushing and maintain ride comfort.

Larger tire and wheel combinations may increase leverage on suspension, steering, and related components.

Due to payload options and initial ride height variances, the amount of lift/lower is a base figure. Final ride height dimensions may vary in accordance to original vehicle ride height. Always measure the vehicle ride height prior to beginning installation.

## Warnings and Disclaimers

### SAEJ2492 Warning

By installing this product, you acknowledge that the suspension of this vehicle has been modified. As a result, this vehicle may handle differently than that of factory-equipped vehicles. As with any vehicle, extreme care must be used to prevent loss of control or roll-over during sharp turns or abrupt maneuvers. Always wear seat belts, and drive safely, recognizing that reduced speeds and specialized driving techniques may be required. Failure to drive this vehicle safely may result in serious injury or death. Do not drive this vehicle unless you are familiar with its unique handling characteristics and are confident of your ability to maintain control under all driving conditions. Some modifications (and combinations of modifications) are not recommended and may not be permitted in your state. Consult your owner's manual, the instructions accompanying this product, and state laws before undertaking these modifications. You are responsible for the legality and safety of the vehicle you modify using these components.

### Headlamp Warning

A lifted or lowered vehicle may have different headlight aim performance. LOGIQ™ recommends marking and recording the headlight beam position before kit installation and then adjusting, if necessary, the headlamps to the same height settings after kit installation. Set the vehicle on a level surface 10' to 15' from a solid wall or garage door. (This is a general distance with some manufacturers requiring different distances.) Note the top height of the low beam's bright spot, the top of the most intense part of the beam, for driver and passenger side. Height may vary from side to side. Repeat this procedure and adjust after lift kit is installed. Adjust if the aim is off by turning the adjusters gradually (a quarter of a turn) and looking to see where the new alignment falls. It may be easier to block one headlamp while adjusting the other. Consult the owner operation manual for procedures to adjust headlights - many automakers offer headlight aiming specs. Some states have their own specifications when it comes to headlight aim, so it's best to follow those rules when aligning headlights.

**FAILURE TO PERFORM THE POST INSPECTION CHECKS MAY RESULT IN VEHICLE COMPONENT DAMAGE AND/OR PERSONAL INJURY OR DEATH TO THE DRIVER AND/OR OTHERS.**

### Final Checks & Adjustments

Once the vehicle is lowered to the ground, check all parts which have rubber or urethane components to ensure proper torque. Torque lug nuts to the wheel manufacturer specs. Move vehicle backwards and forwards a short distance to allow suspension components to adjust. Turn the front wheels completely left then right and verify adequate tire, wheel, brake line, and ABS wire clearance. Test and inspect steering, brake and suspension components for tightness and proper operation. Inspect brakes hoses and ABS lines for adequate slack at full extension, adjust as necessary.

**RECHECK ALL HARDWARE FOR PROPER TORQUE VALUES AFTER 500 MILES, AND THEN PERIODICALLY AT EACH SERVICE INTERVAL THEREAFTER.**

### Vehicle Handling Warning

Increasing the height of your vehicle raises the center of gravity and can affect stability and control. Use caution on turns and when making steering corrections.

Vehicles with larger tires and wheels will handle differently than stock vehicles. Take time to familiarize yourself with the handling of your vehicle.

### Wheel Alignment/Headlamp Adjustment

It is necessary to have a proper and professional wheel alignment performed by a certified alignment technician. Align the vehicle to factory specifications. It is recommended that your vehicle alignment be checked after any off-road driving.

In addition to your vehicle alignment, for your safety and others, it is necessary to check and adjust your vehicle headlamps for proper aim and alignment. If the vehicle is equipped with active or passive safety/collision monitoring and/or avoidance systems including, but not limited to, camera- or radar-based systems, check and adjust your vehicle's systems for proper aim and function.