Thank you for choosing Rough Country for all your suspension needs.

Rough Country recommends a certified technician install this system. In addition to these instructions, professional knowledge of disassemble/reassembly procedures as well as post installation checks must be known. Attempts to install this system without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle.

Please read instructions before beginning installation. Check the kit hardware against the parts list on this page. Be sure you have all needed parts and know where they go. Also please review tools needed list and make sure you have needed tools.

PRODUCT USE INFORMATION

As a general rule, the taller a vehicle is, the easier it will roll. Seat belts and shoulder harnesses should be worn at all times. Avoid situations where a side rollover may occur.

Generally, braking performance and capability are decreased when larger/heavier tires and wheels are used. Take this into consideration while driving. Do not add, alter, or fabricate any factory or after-market parts to increase vehicle height over the intended height of the Rough Country product purchased. Mixing component brands is not recommended.

Rough Country makes no claims regarding lifting devices and excludes any and all implied claims. We will not be responsible for any product that is altered.

If question exist we will be happy to answer any questions concerning the design, function, and correct use of our products.

NOTICE TO DEALER AND VEHICLE OWNER

Any vehicle equipped with any Rough Country product should have a "Warning to Driver" decal installed on the inside of the windshield or on the vehicle's dash. The decal should act as a constant reminder for whoever is operating the vehicle of its unique handling characteristics.

INSTALLING DEALER - it is your responsibility to install the warning decal and forward these installation instructions on to the vehicle owner for review. These instructions should be kept in the vehicle for its service

Kit Contents:	Torque Specs:			
7579 Kit Box 2– Front Coil Spring Spacers	Size 1/2" 9/16"	Grade 5 65 ft/lbs 95 ft/lbs	Grade 8 90 ft/lbs 130 ft/lbs	
Tools Needed:	5/8" 3/4"	135 ft/lbs 185 ft/lbs	175 ft/lbs 280 ft/lbs	
10mm Wrench 14mm Socket 16mm Wrench 16mm Socket 18mm Wrench 18mm Socket 19mm Deep Well Socket Jack Jack Stands	6MM 8MM 10MM 12MM	Class 8.8 5 ft/lbs 18ft/lbs 32ft/lbs 55ft/lbs	Class 10.9 9 ft/lbs 23 ft/lbs 45ft/lbs 75ft/lbs	


FRONT INSTALLATION INSTRUCTIONS

- 1. Jack up the front of the vehicle and support the vehicle with jack stands, so that the front wheels are off the ground. Chock rear wheels.
- 2. Remove the front tires/wheels, using a 19mm deep well socket
- 3. Using a 18mm socket and wrench remove the bottom sway bar bolts. Retain hardware for later use. See PHOTO 1
- 4. Remove the lower shock bolt using a 18mm socket and wrench. Using a 14mm wrench unbolt the top of the shock and remove. **See PHOTO 2.**





- 5. Push down on the axle to allow room for the coils to be removed. Remove coil springs, and factory spring isolator.
- 6. Install the spacer over the factory bump stop with the lip of the spacer pointing down. See PHOTO 3.
- 7. Reinstall the factory coil spring, and the factory spring isolator. Be sure to rotate the spring until the pigtail hits the stop. **See PHOTO 4.**





POST INSTALLATION INSTRUCTIONS

- 1. Check all fasteners for proper torque. Check to ensure there is adequate clearance between all rotating, mobile, fixed and heated members. Check steering for interference and proper working order. Test brake system.
- 2. Perform steering sweep. The distance between the tire sidewall and the brake hose must be checked closely. Cycle the steering from full turn to full turn to check for clearance. Failure to perform inspections may result in component failure.
- 3. Re torque all fasteners after 500 miles. Visually inspect components and re torque fasteners during routine vehicle service.
- Readjust headlights to proper settings.

Maintenance Information

It is the ultimate buyers responsibility to have all bolts/nuts checked for tightness after the first 500 miles and then every 1000 miles. Wheel alignment steering system, suspension and driveline systems must be inspected by a qualified professional mechanic at least every 3000 miles