

Installation Instructions

Eibach Springs, Inc. • 264 Mariah Circle • Corona, California 92879-1751 • USA • Tech Support 800-222-8811 Ext 114



Anti-Roll-Kit # 35125.312

2011 Ford Mustang, Mustang GT, 3.7L V6, 5.0L V8, Incl. Convertible

2011 Ford Mustang Shelby GT500

Kit Contents	Description	Part Number	Qty
	Rear Bar	35125.320R	1
	Anti-Roll Hardware Kit	35125.312HK	1
	Information Kit	EPAK	1
	Instructions	35125.312INST	1

NOTES: **Read All Instructions Before Beginning Installation**


- **Only qualified mechanics experienced in the installation and removal of suspension components should perform this installation.**
- **Use** of a hoist and screw jack is highly recommended and will substantially reduce installation time.
- **Installation time:** Is approximate **1.5** hours with the use of a hoist.
- **Never work on or under a vehicle unless it is properly supported.**
- **Tire Rotation:** In order to increase the life of your tires, it is recommended to rotate your tires every 3,000 miles.

Additional Eibach Components Available For Your Car

Eibach Kits	Part Number	Description	Front	Rear
<i>Pro-Kit</i>	35125.140	High Performance Handling	.8-1.0"	1"-1.5"
<i>Sportline</i>	4.12535	Extreme Lowering	1.1-1.4"	1.5-2.0"

FACTORY REAR BAR REMOVAL & INSTALLATION

1. **Note:** 6cyl models not equipped with a factory rear anti-roll bar will go directly to step 4.
2. Remove the two outer clamps and bushings and factory hardware securing the end of the bar to the rear lower shock mounts. This factory hardware will not be reused. (See photos 4 & 5 on following page)




(Photo 4)



(Photo 5)

3. Next remove the top end link bolt securing the bar to the car, use caution, as the bar will become loose. Remove the rear bar from the car completely. (See photo 6)



(Photo 6)

4. Now you are ready to assemble the new Eibach rear end links and secure them to the new Eibach rear bar. Using photo 6 as a guide apply the supplied lubricant to the inside of the new top end link bushings and install the bushing and sleeve in the link. Lubricate the inside portion of the lower bushings and install on the new Eibach rear bar. Attach end link to bar making sure the "cap" portion is towards the rear of the car. Install the assembly in the car with the new supplied bolt and nut. (See photos 7 & 8)




(Photo 7)




(Photo 8)

5. Install your new Eibach Anti-Roll bar in the car loosely by securing the end links to the factory mounts with the supplied nut and bolt for each side. (See photo 9 on following page)



(Photo 9)

6. Now you are ready to connect the ends of the bar to the rear lower shock mounts with the Eibach supplied hardware. Photo 10 shows the assembly order of the parts required to make this connection. (See photo 10)




(Photo 10)

7. Lubricate the inside of the end bushings and install them on the bar with the "cut" portion towards the ground. Loosely secure the bushing clamp to the lower shock mount and backing plate with two bolts, four washers and two nylok nuts per side, do not tighten at this time. (See photos 11 & 12)



(Photo 11)



(Photo 12)

8. With all the above steps complete and rear connections still loose, re-install the wheels and tires and set car on the ground under it's own weight. With the car sitting under it's own weight or on a drive on type of hoist, tighten all connections in the rear. This is done to prevent bushing pre-load and premature wear of the bushings.