



advanced FLOW engineering

Instruction Manual P/N: 46-20518-B

BladeRunner – Charge Pipe Kit

Make: **Ford**

Model: **F-150**

Year: **2021-2024**

Engine: **V6 – 3.5L(tt)**

Make: **Ford**

Model: **F-150 Raptor**

Year: **2021-2024**

Engine: **V6 – 3.5L(tt)**



- Please read the entire instruction manual before proceeding.
- Ensure all components listed are present.
- If you are missing any of the components, call customer support at 951-493-7100.
- Ensure you have all necessary tools before proceeding.
- Do not attempt to work on your vehicle when the engine is hot.
- Disconnect the negative battery terminal before proceeding.
- Retain factory parts for future use.


Label	Qty.	Description	Part Number
A	1	Tube, Hot Side Upper DS: 46-20518	05-61231B
B	1	Tube, Hot Side Lower DS: 46-20518	05-61232B
C	1	Tube, Hot Side Upper PS: 46-20518	05-61233B
D	1	Tube, Hot Side Lower PS: 46-20518	05-61234B
E	2	Coupling, Silicone Rdr: (1.75"x 2.5") 35 Deg	05-61084
F	2	Coupling, Silicone Hump: 2.5"ID x 4"L	05-60439
G	2	Coupling, Silicone Hump: 2.5" ID x 5.5"L	05-60610
H	2	Clamp, SmartSeal, 032 (1.95" – 2.32")	03-50655
I	10	Clamp, Spring Loaded T-Bolt: 2.85" Dia	05-60039
J	2	Plug, Hex Hd Socket: 1/8" NPT (Zn Plt)	03-50029
K	1	Mount, Aluminum: M8x1.25x7	05-01547


Installation will require the following tools:

7mm socket, 10mm socket, 7/16" deep socket, 5mm allen wrench, 3/16" allen wrench, 6" extension, ratchet, pick, thread sealant, & grease.


Warranty Information available at <https://afepower.com/contact#warranty>

Note: Legal in California for use on race vehicles only. The use of this device on vehicles used on public streets or highways is strictly prohibited in California and others states that have adopted California emission regulations.






1. Park vehicle on level ground and engage the parking brake.
2. Disconnect the negative battery cable.
3. Remove the two nuts securing the engine cover to the vehicle, then remove the cover from the vehicle①
4. Disconnect the air intake temperature sensor from the air intake tube and unclip harness from the air box②
5. Loosen the clamps securing the air intake tube(s) onto the air box and the turbo inlet tubes③
6. Unclip the top of the air box from the bottom of the air box④then remove the air intake tube(s) and top from the vehicle.



7. Loosen all of the clamps securing both hot side charge pipes to the intercooler from underneath⑤ then remove the couplings from the vehicle.
8. Loosen the clamp securing the hot side charge pipe to the turbo outlet coupling on the passenger side⑥
9. Lubricate the mounting grommet⑦ and disconnect the charge pipe from its mount and the turbo coupling then remove the pipe from the vehicle.
10. Loosen the clamp securing the hot side charge pipe coupling to the passenger side turbo, then remove the coupling from the vehicle.




11. Disconnect the PCV hose from the driver's side turbo inlet tube ⑧
12. Disconnect the vent hose to the charge pipe and the turbo inlet tube ⑨ then remove from the vehicle
13. Loosen the clamp securing the hot side charge pipe to the turbo outlet coupling on the driver's side ⑩
14. Lubricate the mounting grommet ⑪ and disconnect the charge pipe from its mount and the turbo coupling, then remove the charge pipe from the vehicle from the top.
15. Loosen the clamp securing the hot side charge pipe coupling to the driver's side turbo, then remove the coupling from the vehicle.




Note: Be sure to use thread sealant on the plugs or sensors to prevent any leaking.

16. If you are not using any aftermarket sensors, install the supplied 1/8" NPT plugs (12) into the threaded fittings on the aFe charge pipes.
17. Install the supplied Aluminum Mount into the threaded fittings on the driver's side upper hot charge pipe.



Note: Be sure to thoroughly clean all oil residue off of the connections before installing any of the aFe couplings onto the vehicle.

18. Install the supplied aFe silicone Rdr: (1.75"x 2.5") 35 Deg coupling and one supplied SmartSeal, 032 (1.93" – 2.32") clamp onto the passenger side turbo outlet (13) do not tighten the clamp yet.
19. Install the supplied aFe passenger side upper hot charge pipe into the vehicle with one 2.85" spring-loaded T-Bolt clamp (14) ensure the mounting pin goes into the factory grommet, do not tighten the clamps yet.
20. Install the supplied aFe silicone hump: 2.5"ID x 4"L coupling and one supplied 2.85" spring-loaded T-Bolt clamp onto the aFe passenger side upper hot charge pipe (15) do not tighten the clamp yet.
21. Install the supplied aFe passenger side lower hot charge pipe into the vehicle along with one 2.85" spring-loaded T-Bolt clamp (16) Connect the passenger side lower charge pipe to the upper charge pipe coupling from the previous step.



Note: Be sure to thoroughly clean all oil residue off of the connections before installing any of the aFe couplings onto the vehicle.

22. Install the supplied aFe silicone hump coupling 2.5"ID x 5.5"L and one 2.85" spring-loaded T-Bolt clamp onto the upper hot side intercooler inlet (17) do not tighten the clamp yet.
23. Connect the aFe passenger side lower hot charge pipe to the coupling from the previous step along with one 2.85" spring-loaded T-Bolt clamp (18)




Note: Be sure to thoroughly clean all oil residue off of the connections before installing any of the aFe couplings onto the vehicle.

24. Install the aFe silicone Rdr: (1.75"x 2.5") 35 Deg coupling and the remaining SmartSeal, 032 (1-15/16" - 2-5/16") clamp onto the driver's side turbo outlet (19) do not tighten the clamp yet.
25. Install the supplied aFe driver's side upper hot charge pipe into the vehicle with one 2.85" spring-loaded T-Bolt clamp on the passenger side (20) ensure the mounting pin goes into the factory grommet, do not tighten the clamp yet.



Note: Be sure to thoroughly clean all oil residue off of the connections before installing any of the aFe couplings onto the vehicle.

26. Install the remaining aFe silicone hump coupling 2.5"ID x 4"L and one 2.85" spring-loaded T-Bolt clamp onto the longer side of the aFe driver's side lower hot charge pipe (21) do not tighten the clamp yet.
27. Install the remaining 2.5"ID x 5.5"L coupling and one 2.85" spring-loaded T-Bolt clamp onto the lower hot side intercooler inlet (22) do not tighten the clamp yet.
28. Install the aFe driver's side lower hot charge pipe into the vehicle along with one 2.85" spring-loaded T-Bolt clamp (23) Connect the driver's side lower charge pipe to the lower intercooler coupling from the previous step, and then to the upper charge pipe from Step 25.



29. Reconnect the vent hose to the charge pipe and the turbo inlet tube, ensure the retaining clips lock into place (24)
30. Reconnect the PCV hose from the driver's side turbo inlet tube (25)
31. Reconnect the MAP sensor connector to the charge pipe (26)
32. Ensure the aFe hot side charge pipes are not touching anything and tighten all of the clamps.



- 33. Reinstall the air intake tube(s) and top of the air box into the vehicle and tighten the clamps (27)
- 34. Reconnect the air intake temperature sensor to the air intake tube and clip harness onto the air box (28)
- 35. Reinstall the engine cover (29)
- 36. Reconnect the negative battery cable.
- 37. Install is now complete.

Note: Be sure to check all connections after 50-100 miles.

This Page Was Left Intentionally Blank

This Page Was Left Intentionally Blank



advanced FLOW engineering, inc.

252 Granite Street Corona, CA 92879

TEL: 951.493.7100 • TECH: 951.493.7100 x23

E-Mail: Tech@aFepower.com

46-20518-B
05/17/2022 KF