

Cognito Uniball SM Series Upper Control Arm Kit for 2007-2018 GM 1500 2WD/4WD trucks and SUVs with Cast Steel Control Arms

INSTALL INSTRUCTIONS:

Cognito Uniball SM Series Upper Control Arm Kit for 2007-2018 GM 1500 2WD/4WD trucks and SUVs with Cast Steel Control Arms
SKU: 110-90296

PARTS LIST FOR SKU: 110-90296

QUANTITY	PART #	DESCRIPTION
4	6878	Pivot Bushing Assembly
1	8191	2007-2018 GM 6-Lug Upper Control Arm, Driver
1	8192	2007-2018 GM 6-Lug Upper Control Arm, Passenger
2	HARDWARE-10743-03441	2.125" Internal Retaining Ring
2	UNI-BALL-WSSX16T-F1	Uniball WSSX16T 1.00" w/ F-1 Fit & Teflon Liner.
2	HP9227	Hardware Pack



WARNING

The upper control arm is not designed to function as a droop limiter. Ball joint failure may occur if the control arm is installed with an incompatible shock. The maximum shock length depends on each lift specification, but in all installations, it is critical that the control arm ball joint does not bind or over articulate.

Please read this entire instruction sheet before beginning installation. Proper installation of these components requires a qualified mechanic. Always wear safety glasses when using power tools, and take appropriate precautions when working under a vehicle. If these instructions are not properly followed you may jeopardize your, and your passenger's safety, and severe frame, suspension or tire damage may also result from improper installation.

PARTS LIST FOR SKU: HP9227

QUANTITY	PART #	DESCRIPTION
1	5309	Uniball Hat
1	5363	2007-2018 GM 6-Lug Uniball Pin
1	HARDWARE-13003	1/4"-20 X 3/4 Grade 5 Zinc Hex Head Cap Screw
2	HARDWARE-33078	1/4" SAE Zinc Flat Washer
1	HARDWARE-37260	1/4"-20 Grade C Zinc Top Lock Nut
1	HARDWARE-33086	1/2" SAE Zinc Flat Washer
1	HARDWARE-NYLOCK-1/2-20	1/2"-20 Grade 8 Zinc Nylock Nut
1	HARDWARE-33092	3/4" SAE Zinc Flat Washer
1	HARDWARE-NYLOCK-3/4-16	3/4"-16 Grade 8 Zinc Nylock Nut
3	HARDWARE-63124	6" Black Cable Tie



INTRODUCTION

The Cognito Uniball SM Series Upper Control Arm Kit is a direct replacement for the factory upper control arms (UCAs) on 2007-2018 GM 1500 2WD/4WD Trucks and 2007-2018 SUVs with Cast Steel Control Arms. Specifically for leveled and lifted applications where an upgrade is desired to provide better performance, style, and function. The boxed sheet metal arms are powder coated semi-gloss black. FK Uniball joints are included as well as new bushings. Ample droop travel is required for good ride quality and all suspension components to last and work properly. This control arm kit will add performance to the Chevy and GMC truck by correcting the Uniball angle for lifted and leveled applications. The allowable droop travel is also improved with the design of these arms. Made in the USA.

REQUIREMENTS


- **The upper control arm is not designed to be the droop limiter, ball joint failure will occur if the upper arm is used as the droop limiter. A shock or limit strap is required to be the limiter. It is required that the proper length shock from Cognito or a limit strap kit from Cognito be installed to prevent failure which could cause an accident and serious injury.**
- Cutting off the service perch on the frame under the front upper arm pivot is required.
- The stock wheel and tire will fit with this UCA kit. Using a tire larger than the factory tires on the factory wheels may result in interference issues (rubbing, damage, noises, etc.).
 - Use of appropriate wheel spacers, and proper fender trimming may be required depending on aftermarket wheel and tire.
- Installation requires a qualified mechanic.
- Follow the OE specifications when replacing or re-installing OE fasteners, retainers, and hardware specified in the OEM manual.
- Always wear safety glasses when using power tools.
- When a lift is required to perform the installation of these products and always ensure the vehicle is properly supported before attempting installation or serious injury may occur.

TECH NOTES

- Read instructions carefully and study the pictures (if included) before attempting installation.
- If this product was purchased as part of a bundle/package. Familiarize yourself with each set of instructions included with the bundle/package before beginning.
- Check the parts and hardware packages against the parts list to assure that your kit is complete before starting.
- If the arm is equipped with grease fittings, service should be performed every 3,000 – 5,000 miles.

INSTALLATION

1. **It is critical that the correct length shock is used**, using a shock that is too long will cause the upper ball joint to bind and break. **For this upper control arm kit, when used in a stock-height or leveling application, the maximum shock length that can be used is 20.4" from the center of the lower eyelet to the mounting face at the top of the strut hat. Any spacers added to the shock must be included in this measurement** (see figure 1). If this UCA kit is used with any other parts then specified, warranty will be void on this arm kit, and damage may occur to arms, ball joints, tie rods, cv axles and possibly more.



2. Rack the vehicle and lift it off the ground, or if no hoist is available then jack front of truck off the ground and support properly with jack stands. Remove the front tires and set them as side.
 - **NEVER WORK ON AN UNSUPPORTED VEHICLE.**
3. Support the lower control arms with a floor jack or stand prior to removing the upper control arms (UCAs).
4. Remove the factory upper control arms. Loosen the ball joint nut of the upper control arm enough until the nut can be spun by hand, but do not remove totally. Use a pickle fork to separate the ball joint from the spindle or tap on the side of the spindle next to the ball joint stud. When the tapered seat of the ball joint breaks loose remove the ball joint nut, and separate the factory upper control arm from the spindle.
5. Remove the factory bolts and eccentric washers that connect the control arm to the frame but retain them for future use. Place them aside in order so they can be re-installed in the same place they came off. The plastic inserts will need to be removed and discarded from the eccentric washers.

6. Due to the added droop travel when using the Cognito upper control arms, the service perch under the upper control arm which is welded to the frame, must be cut off. Locate a cutting tool (such as a reciprocating saw) and cut both the service perch located on the front upper control arm pocket. The cut will be parallel to the front upper control arm pocket.

- **NOTE:**

Take great care to keep the lines and wires safe during the cut and make sure to shield them from sparks if any kind of grinder is used.

Wear safety glasses!

Exposed raw metal should be coated or painted to prevent corrosion.

Warranty on Cognito products will be void if damage occurs due to collision with the factory service perch.

Figure 2: Factory Frame Service Perch Cut Reference






Figure 3: Service Perch Removed



7. The shock tower must also be trimmed to prevent the a-arm contacting. The vertical cut is in line with the front of the a-arm pocket and the horizontal cut is in line with the top of the a-arm pocket.



8. Locate **HP9227**, Remove **5309**, Uniball Hat, **5363**, Uniball Pin, and the 3/4" washer and nut from the hardware pack. Insert **5363** through the Uniball from the bottom. Push **5309** onto the straight end of the tapered stud from the top, and into the Uniball. This will be a snug fit and may be a slight press fit, tap with soft faced mallet if needed. Install the 3/4" flat washer and locknut, do not fully tighten yet.
 - **NOTE:**
It is highly recommended to use anti-seize lubricant when installing **5309** & **5363** to prevent galling. The uniball pin and hat are made from stainless steel and will gall under load if not lubricated, lubricate all mating surfaces and threads to prevent galling.
9. Mount the Cognito upper control arms to the frame with the factory nuts, bolts, and eccentric washers as previously removed. Set the alignment bolts about in the middle of the slot of the eccentric washers and torque alignment nuts to **90 ft-lbs.**



10. Mount the uniball pin to the spindle with supplied hardware. Use the 1/2" flat washers supplied, then torque the nut to **60 ft-lbs.**
 - **NOTE:**
It is highly recommended to use anti-seize lubricant on the pin taper and threads to prevent galling. The lower side of the tapered hole in the spindle may be slightly too small to allow the Cognito tapered stud to seat properly. If this is the case, chase the small end of the hole with a 1/2" drill bit, removing only a very small amount of material to allow the stud to seat into the spindle.
11. Torque the 3/4" nut of the uniball pin assembly to **90 ft-lbs.**
12. If there were factory lines mounted to the factory upper control arms such as ABS or brake lines, they must be restrained to avoid binding and contact with any moving parts of the vehicle. Use the 1/4" hardware provided to fasten the factory brake line bracket to the Cognito upper control arm if applicable. If necessary, slide the brake line through the factory bracket to obtain a suitable mounting situation.
13. Remove the abs line clip from the top of the frame shock pocket and use the cable ties to restrain the abs line to the brake line.
14. Ensure that all bolts are properly torqued. Ensure there are no rubbing or loose cables anywhere after the Cognito UCA installation. Use cable ties to restrain any cables from interfering with any other part. Check that all lines are free of stress or interference while the vehicle is in full droop, full bump, and throughout the complete steering cycle.
15. Install front wheels and tires and torque lug nuts to factory manufacturer's specifications.

16. Before lowering the vehicle, measure from the top of the wheel well directly above the center line of the wheel to the top of the tire, see Figure 5. Record this measurement as (A) in Table 1. Subtract 3 inches from A and record this number.

- Note:**

It can be helpful to place a piece of painter's tape at the top of the wheel well directly above the centerline of the wheel and measure from there.

17. Set the truck on the ground and drive forward and backward a few times to settle the suspension. Measure again from the top of the tire to the top of the wheel well as in the step above and record this measurement as (C) in Table 1.

- Note:**

If (C) is larger than (B), the ride height is too tall. This can be caused by shocks or shock spacers that are too long, stacked shock spacers, spring preload devices, or any combination of the above.

Failure to use compatible shocks to limit the vehicles front suspension may cause over-extension, which as a result can cause damage to ball joints, uni-balls, tie rods, and/or CV axles, along with other related safety issues.

Warranty on Cognito products will be void if the vehicles front suspension is not properly limited to the above max ride height calculation.

Suspension Travel	Record	Measurement (Inches)
Full Droop	A	
Max Ride Height	$B = A - 3 \text{ in}$	
Ride Height	C	

Table 1. Suspension Travel Measurements

Figure 5: Measuring and Setting Ride Height





18. Adjust headlights per owner's manual.
19. Check wheel and tire clearance one last time through the steering cycle. Make adjustments as needed.

20. **Have the vehicle professionally aligned.**

- **NOTE:**

Some Cognito upper control arms have added caster built into them to increase drivability performance, therefore it's important to be sure the correct control arm is installed on the correct side of the vehicle. It's also important to make your alignment shop aware that if caster is higher than normal for OEM, that is the intention by design.

Cross caster is important in making your vehicle track straight down the road. Most roads have crown to them, high in the middle for water runoff. This crown will make your vehicle want to pull to the right. Vehicles with stock tires on them have a narrow contact patch on the ground and are not as affected as a vehicle having larger wider tires. With larger wider tires it's important to have cross caster proper in order for the vehicle to track straight on these roads. Trucks with dual rear wheels have more tire on the ground and require more cross caster. The length of the wheelbase will also affect cross caster needed.

Generally, crew cab short and long bed trucks like .8 degrees of cross caster. For example, the driver side would have 2° while the passenger side would have 2.8° of caster. Dual rear wheel trucks like .9-1.0 degrees of cross caster. Your area might have roads that are crowned more or less than average therefore these numbers may need to change, and your alignment shop should understand this. If your alignment tech is stating they can't align the truck, that typically means they can't get the alignment to OEM spec, and that's fine because your vehicle is no longer OEM. A good tech will understand this and the numbers and let caster run slightly out of OEM spec (Caster should always be above 2 degrees positive) while maintaining cross caster needed for the vehicle and roads so you enjoy your vehicle with aftermarket Cognito parts and your driving experience. Camber should always be from -.1° to +.1° and toe should always be .125" to .250" toe in for best tire wear.

This completes the installation steps, enjoy your new Cognito SM Series Uniball Upper Control Arm Kit!



WARRANTY / RETURN POLICY / SAFETY

Cognito Limited Lifetime Warranty

Cognito Motorsports, Inc. hereinafter “Cognito,” warrants to the original retail purchaser, that its suspension products are free from workmanship and material defects for as long as the purchaser owns the vehicle on which the product(s) were originally installed. This warranty will be void if any modifications are made to the components, including alterations to the surface finish, i.e.; painting, powder coating, plating, and/or welding, or if they are improperly installed. Cognito truck suspension products are not designed nor intended to be installed on “competition” vehicles used in race applications, stunt or for exhibition purposes that are outside of the intended operating conditions specified by the manufacturer. Racing and competition are defined as any contests between two or more vehicles; or vehicles competing individually on off road circuits in timed events (whether or not such contests are for an award or prize).

This warranty does not include coverage for police, taxi, government or commercial vehicles, and the warranty does not cover Cognito products sold outside of the USA. Cognito’s obligations under this warranty are specified and applied at its sole discretion, and warranty coverage is limited to repair or replacement of the defective product(s). Any and all costs of removal, installation or reinstallation; freight charges, incidental or consequential damages associated with the covered products are expressly excluded from this warranty.

The following items are exempt from Cognito limited warranty coverage: bushings, bump stops, tie-rod ends (Heim joints) and limiting straps. These parts are “consumables” and designed to wear as a normal part of their duty cycle, therefore they are not considered defective when worn. The aforementioned products are warranted separately against defects in workmanship, for 60 days from the date of purchase. As a condition of warranty validation, respective Cognito suspension components must be installed as a complete system (not combined with non-Cognito hardware or ancillary parts). Any substitutions or omission of required components will void the warranty. Some minor cosmetic wear and imperfections may occur to parts during shipping, which is not covered under this warranty. This limited warranty does not apply to any components that have been subjected to collision damage, negligence, alteration, abuse, or misuse, and coverage does not extend to products manufactured by third-party companies. Cognito reserves the right to supersede, discontinue, or change the design, finish, part number and/or application of its parts when deemed necessary, without notice.

Return Policy

Product returns will not be accepted without prior written approval from an authorized Cognito representative. All products being returned must be shipped via trackable, prepaid freight. Returned products are subject to a 25% percent restocking fee. The eligible return period for products purchased directly from Cognito is 30 days from the verified date when the product(s) were originally received by the purchaser.

Product Safety Advisory

The installation of Cognito steering and suspension components will modify your vehicle’s original factory equipment and geometry, which may cause it to handle differently than a stock (unaltered) vehicle. Installation of these components is not intended to strengthen nor reinforce the vehicle’s frame, nor are they designed to increase rollover protection. It is necessary to periodically inspect all suspension and drive train components for proper attachment, torque specifications, operation, and for any potential unusual wear or damage. Installation of these parts will modify the height of the vehicle and may raise the center of gravity. Modifying vehicle height combined with off road operation may increase your vehicle’s susceptibility to rollover conditions, which may cause serious injury or death. Many states regulate allowable vehicle height modifications, and it is your responsibility to know and comply with the legal requirements specified by the laws where you reside. Modifications to your vehicle’s ride height may also affect the ride quality, driver input response, trackability and handling, and wear to your vehicle’s suspension components and tires.